

# Application, Installation, & Service Manual

R/RH-Series Liquid to Air Heat Pumps

Single-Stage R410a Model Sizes 09-24





info@nordicghp.com www.nordicghp.com 002512MAN-01



SAFETY PRECAUTIONS



- WARNING: Ensure all access panels are in place and properly secured before applying power to the unit. Failure to do so may cause electrical shock.
- WARNING: Before performing service or maintenance on the heat pump system, ensure all power sources are DISCONNECTED. Electrical shock can cause serious personal injury or death.
- WARNING: Heat pump systems contain refrigerant under high pressure and as such can be hazardous to work on. Only qualified service personnel should install, repair, or service the heat pump.
- **CAUTION:** Safety glasses and work gloves should be worn at all times whenever a heat pump is serviced. A fire extinguisher and proper ventilation should be present whenever brazing is performed.
- **CAUTION:** Venting refrigerant to atmosphere is illegal. A proper refrigerant recovery system must be employed whenever repairs require removal of refrigerant from the heat pump.

#### -18—HAC—P—1L—C—SDELT—01 Series: ← **Revision:** R = liquid to air, vertical config. 01, 02 etc. RH = liquid to air, horizontal config. Air Supply Orientation: T = top Nominal Size: + F = field configurable 09 = 0.75 Ton (end or side) 12 = 1 Ton 18 = 1.5 Ton Air Return Orientation: 24 = 2 Ton L = left return R = right return **Blower Motor:** Functions: E = ECM (5spd)H = Heating AC = Active Cooling **Blower Type:** D = direct drive Refrigerant: P = R410aAir Coil: S = standard (non-coated) Voltage Code: + K = e-coated 1 = 208/230-1-60 VAC (factory set to 230-1-60) 3 = 265/277 - 1 - 60**Outdoor Loop Exchanger:** 9 = 208/230-1-60 VAC (factory set to 208-1-60) C = copperZ = CuNi coil Compressor: L = 1 Stage Rotary

## **Model Nomenclature**

APPLICATION TABLE											
SERIES	MODEL SIZE	FUNCTION	REFRIGERANT	VOLTAGE	COMPRESSOR	OUTDOOR COIL	FAN/CASE		REVIS	IONS	
R	09	HAC	Р	1 3 9	L	C Z	SDELT SDERT	02	03		
R	12	HAC	Р	1 3 9	L	C Z	SDELT SDERT	02	03		
R	18	HAC	Р	1 3 9	L	C Z	SDELT SDERT	02	03		
R	24	HAC	Р	1 9	L	C Z	SDELT SDERT	02	03		
RH	09	HAC	Ρ	1 3 9	L	C Z	SDELT SDERT	03	04		
RH	12	HAC	Р	1 3 9	L	C Z	SDELT SDERT	03	04		
RH	18	HAC	Р	1 3 9	L	C Z	SDELT SDERT	04	05		
RH	24	HAC	Р	1 9	L	C Z	SDELT SDERT	02	03		
This manual applies only to the models and revisions listed in this table.											

go to TABLE OF CONTENTS

Maritime Geothermal Ltd. has a continuous improvement policy and reserves the right to modify specification data at any time without prior notice .

# **Table of Contents**

Tables, Figures, & Documents	5
R/RH-Series System Description	6
General Overview	6
1. Heating Mode	6
Factory Options	6
R-Sories Sizing	7
Heat Pump Sizing	7
Plenum Heater Sizing	7
Installation Basics	8
Sample Bill of Materials - Ground Loop Installations	8
Sample Bill of Materials - Open/Building Loop Installations	8
Unpacking the unit	8
Unit Placement	<u>8</u> 0
Air Return Orientation	9
Plenum Heater Installation (Optional)	9
Wiring	10
Power Supply Connections	10
Outdoor Loop Pump Module Wiring (Ground Loop Only)	10
Control Transformer	10
Thermostat Requirements	10
Blower Motor	10
Safety Controls	11
Open/Closed Loop LPC Selection	11
Piping	12
Condensate Drain	12
Outdoor Loop	12
	15
Ductwork	14
Blower Motor	14
Duct Systems - Grill Lavout	14
Thermostat Location	14
Plenum Heater	14
<u>001201CDG - Typical Duct and Condensate Connections</u>	15
	10
Ground Loop Installations	17
Circulator Pump Module	17
Adding Antifreeze Solution	18
Initial Pressurization	18
Pipe Insulation	18
Low Pressure Control Selection	18
000609INF - Typical Honz. Ground Loop Configuration	20
000906CDG - Circulator Pump Module Installation	21
002336PDG - Pump Module Inst - 2 Units on 1 Loop	22
Open Loop Installations	23
Well Water Temperature	23
Well Water Flow	23
Well Water Quality	23
Water Valve	23
Low Pressure Control Selection	24
Water Flow Control	25
Submersible Pump Selection	25
Pipe Insulation	25
000619INF - Ground Water Disposal Methods	26

Startup Procedure	27
Pre-start Inspection	27
Unit Startup	28
Startup Record	29
Routine Maintenance	30
Maintenance Schedule	30
Troubleshooting Guide	31
Repair Procedures	38
Pumpdown Procedure	38
General Repair Procedure	38
Vacuuming & Charging Procedure	38
Compressor Replacement Procedure	39
Model Specific Information	40
Refrigerant Charge	40
Shipping Information	40
Operating Temperature Limits	40
Pressure Drop Data	41
Standard Capacity Ratings	42
Performance Tables: R-09	43
Performance Tables: R-12	44
Performance Tables: R-18	45
Performance Tables: R-24	46
Electrical Specifications	47
Plenum Heater Electrical Specifications	47
Wiring Diagram (208/230-1-60)	48
Wiring Diagram (265/277-1-60)	49
Refrigeration Circuit - Heating Mode	50
Refrigeration Circuit - Cooling Mode	51
Dimensions: R-09/12 Left Return	52
Dimensions: R-09/12 Right Return	53
Dimensions: R-18/24 Left Return	54
Dimensions: R-18/24 Right Return	55
Dimensions: RH-09/12 Left Return	56
Dimensions: RH-09/12 Right Return	57
Dimensions: RH-18/24 Left Return	58
Dimensions: RH-18/24 Right Return	59
Warranty	60

# **Tables, Figures, & Documents**

Tables	Table 1 - Heat Pump Size vs. Heated Area for a Ground Loop System	7
Tables	Table 2 - Heat Pump Size vs. Heated Area for an Open/Building Loop System	7
	Table 3 - Plenum Heater Sizing	7
	Table 4 - Power Supply Connections (Heat Pump)	
	Table 5 - Power Supply Connections (Plenum Heater)	
	Table 6 - Control Signal Description	
	Table 7 - Airflow	
	Table 8 - Control Board Fault Codes	
	Table 9 - Heat Pump Size vs. Hot Air Grills	
	Table 10 - Duct Sizing Guide	
	Table 11 - Antifreeze Percentages	
	Table 12 - Volume of Fluid per 100ft, Of Pipe	
	Table 13 - Required Open Loop Flow	
	Table 14 - Refrigerant Charge	
	Table 15 - Shipping Information	
	Table 16 - Operating Temperature Limits	
	Table 17 - Loop Pressure Drop Data	
	Table 18 - Standard Capacity Ratings - Ground Loop Heating 60Hz	43
	Table 19 - Standard Capacity Ratings - Ground Water Heating 60Hz	
	Table 20 - Standard Capacity Ratings - Ground Loop Cooling 60Hz	
	Table 21 - Standard Capacity Ratings - Ground Water Cooling 60Hz	
	Table 22 - Electrical Specifications	
	Table 23 - Plenum Heater Electrical Specifications	
	Figure 1 Ground Leon Accessories & Teels	16
rigures	Figure 2 Open Leop Accessories & Tools	10
	Dimonsiones P. 00/12 Loft Potures	<u>24</u> 52
	Dimensions, R-03/12 Leicht Poture	
	Dimensions, N-03/12 Kight Neturn	
	Dimensions, N-10/24 Left Neum	
	Dimensions, N-10/24 Ng/It Neurin	
	Dimensions, NI-69/12 Leit Neum	
	Dimensions, NT-09/12 Ngit Return	
	Dimensions: RH-18/24 Left Return	
Documents	002513CDG - Typical Loop Connections - R/RH Commercial	<u>13</u>
	001201CDG - Typical Duct and Condensate Connections	<u>15</u>
	000608INF - Typical Horizontal Ground Loop Configuration	<u>19</u>
	000609INF - Typical Vertical Ground Loop Configuration	20
	000906CDG - Geo-Flo Circulator Pump Module Installation	21
	002336PDG - Circulator Pump Module Installation - Two Units on One Ground Loop	
	000619INF - Ground Water Disposal Methods	
	001954SCH - R/RH-09/12/18/24 Schematic Diagram 208/230-1-60	
	002124SCH - R/RH-09/12/18/24 Schematic Diagram 277-1-60	
	001766RCD - R(H) 09-24 Refrigeration Circuit - Heating Mode	
	001767RCD - R(H) 09-24 Refrigeration Circuit - Cooling Mode	51

# **R/RH-Series System Description**

#### **General Overview**

The Nordic vertical **R-series** and horizontal **RH-series**, geothermal standards for more than 30 years, are package water source heat pumps that can heat or chill air in a forced air duct system. Being 'ground source', 'water source', 'geo-exchange', or 'geothermal' heat pumps, the R and RH-series do require a **building loop**, **ground loop** or **open loop water well** for a heat source/sink. There is no outdoor fan unit for ground source heat pumps.

The residential **NORDIC R/RH** product line, with premium features expected in a central heating/cooling system, runs from size **25** to **80**. The smaller **R/RH-09** to **24** described in this document aim to economize on price while still maintaining high reliability and many premium features. They are normally considered a 'commercial' product for multiple-unit installations, although they can be employed residentially.

On R/RH-09 to 24, there is no desuperheater for DHW heating. A single stage rotary compressor with built in accumulator is used. The blower motor is an ECM, which has 5 fixed constant torque airflow settings which are selected during installation. The outdoor loop refrigerant to water heat exchanger is a heavy duty coaxial copper / steel model, and an optional CuNi inner tube may be available for challenging water applications (check with factory). A single thermostatic expansion valve (TXV) regulates superheat. The cabinet is constructed from galvanized sheet metal, partly powder coated.

#### **1. Heating Mode**

In heating mode, the heat pump heats warm air in a duct system. As the unit operates, heat is extracted from the ground loop, well water, or building loop. The heat pump is activated by by a standard 2H/1C 24V room thermostat, which will call for heat from the compressor first. The thermostat can also call for stage 2 (due to air temperature falling further below the setpoint, or after a certain run time), which will activate the optional electric plenum heater. The plenum heater accessory is available in different sizes to provide either full backup or partial auxiliary heat.

If a closed ground loop is used, 230v circulation pumps can be powered and controlled by the heat pump; if building loop or open loop, a water valve is opened by the heat pump during heating operation and closed when the heat pump is idle.

### **2. Cooling Mode**

In cooling mode, the heat pump cools air in the duct system. As the unit operates, heat is extracted from the ducted air stream and rejected to the ground loop or well water.

#### **Factory Options**

Looking at the main service panel and piping connections, the heat pump can be ordered as a left or right hand air return from the factory. This must be specified at time of order as the physical construction of the two configurations is different.



go to TABLE OF CONTENT

# **R/RH-Series Sizing**

### **Heat Pump Sizing**

The following table is a rough guideline as to the size of space each heat pump size can handle for **ground loop** (closed loop) installations.

TABLE 1 - Heat Pump Size vs. Heated Area           for a Ground Loop System				
Model	ft <sup>2</sup>	m²		
R/RH-09	300	28		
R/RH-12	400	37		
R/RH-18	600	56		
R/RH-24	800	74		

The following table is a rough guideline as to the size of space each heat pump size can handle for **ground water (open loop)** or **building loop** installations.

TABLE 2 - Heat Pump Size vs. Heated Area           for an Open / Building Loop System				
Model	ft <sup>2</sup>	m²		
R/RH-09	375	35		
R/RH-12	500	46		
R/RH-18	750	70		
R/RH-24	1000	93		

THE TABLES ABOVE ARE FOR ESTIMATION ONLY. THEY SHOULD NOT BE USED TO SELECT A FINAL UNIT SIZE. They simply show what size unit is required for a residential installation with typical construction: R20 walls, R40 ceiling, and average size and number of windows. The heated area is the area of the above grade main level; the tables account for a basement the same size as the heated area.

MARITME GEOTHERMAL LTD. HIGHLY RECOM-MENDS THAT A PROPER HEAT LOSS/GAIN ANALYSIS BE PERFORMED BY A PROFESSIONAL WITH APPROVED CSA F-280 SOFTWARE BEFORE SELECTING THE HEAT PUMP SIZE. For heating dominant climates, we recommend sizing the unit to 100% of the heating design load for maximum long term efficiency with minimal supplementary heat. The unit should be installed as per CSA standard 448.2-02. For ground loop applications, the ground loop should be designed using suitable software with a multi-year analysis.

The analysis will result in a heat load for the coldest day, which is influenced by, for example, the number of levels, the size of the windows, the orientation of the home, attached garage, bonus rooms, walk-in basement, and coldest outdoor temperature for the region.

A heat pump model size can then be selected by comparing the calculated heat load to the heat pump capacity at the design indoor loop temperature, which can be found in the performance tables in the **Model Specific Information** section. For these heat pump series, the *Standard Capacity Ratings* rather than detailed performance tables can be used for simplicity. For 100% heat pump sizing, choose a heat pump with a standard capacity rating that matches or just slightly exceeds the calculated heat load.

Some background on *Standard Capacity Ratings*: closed ground loops are normally designed to reach a minimum temperature of just below freezing at the end of the heating season, in order to take advantage of the latent heat of groundwater (at

least in northern climates). Hence, the Standard Capacity Ratings for Ground Loop Heating should apply in all northern climates. Conversely, the Standard Capacity Ratings for Ground Water (open loop) heat pumps assume a well water temperature of 50°F (10° C). In more southerly climates, the groundwater or ground loop will probably be at a warmer minimum temperature, and it will be necessary to consult the more detailed performance tables for heat pump output at a different ELT.

In cooling dominant climates, the heat pump should be similarly sized using the Ground Loop Cooling or Ground Water Cooling Standard Capacity Ratings. Even in northern heating dominant climates, it should be ensured that 100% of the cooling load will be covered when sizing the heat pump, since there is normally no auxiliary or backup cooling available.

### **Plenum Heater Sizing**

The plenum heater is available as an accessory in 5, 7, 10, 15 and 20 kW sizes. If full backup is desired, choose a size that covers **100% of the coldest day heat load**, according to the heat loss analysis mentioned in the last section. If that is not available, use the following recommendation:

TABLE 3 - Plenum Heater Sizing			
Model	Plenum Heater Size for full backup		
R/RH-09	5 kW (or smaller)		
R/RH-12	5 kW (or smaller)		
R/RH-18	5 kW		
R/RH-24	7 kW		

Be sure to order the 'internally mounted' type of plenum heater, even though on these units it is mounted externally. This is because the "internally mounted" model has a narrower cage that is more suitable for the smaller discharge ductwork used with smaller heat pump sizes.

## **Unpacking the Unit**

When the heat pump reaches its destination it should be unpacked to determine if any damage has occurred during shipment. Any visible damage should be noted on the carrier's freight bill and a suitable claim filed at once.

### **Unit Placement**

Ducted or forced air heat pumps should be centrally located in the building with respect to the conditioned space. This provides the best in economy and comfort and usually can be accomplished in harmony with the design of the space. A heating system cannot be expected to produce an even temperature throughout the space when it is located at one end of the structure and the heated or cooled air is transmitted with uninsulated metal ductwork.

For vertical **R**-series units, the front access panel (on the side where pipes are connected) should remain clear of obstruction for a distance of **2 ft (0.7 m)** to facilitate servicing and general maintenance. No access is required on the left,

#### Sample Bill of Materials -Ground Loop Installations

#### FROM MARITIME GEOTHERMAL

- R/RH SERIES HEAT PUMP (L OR R RETURN)
- PLENUM HEATER 5/7kW
- 2H/1C THERMOSTAT (OR SOURCED ELSEWHERE)
- P/T PORTS AND HOSÈ ADAPTERS (2)
- 1 PUMP PACK
- PIPE ADAPTERS FOR PUMP PACK

#### **OPTIONAL FROM MARITIME GEOTHERMAL**

- ANTI-VIBRATION PAD
- SOUND JACKET

#### DUCTWORK

- OUTLET PLENUM ADAPTER W/ FLEXIBLE COLLAR
- RETURN AIR ADAPTER W/ FLEXIBLE COLLAR
- FIBREGLASS INSULATION (FOR NOISE, IF REQ'D)
- TRUNK DUCT W/ JOINERS (IF NOT EXISTING)
- 6" ROUND DUCT W/ADAPTERS (IF NOT EXISTING)
- ALUMINUM TAPE
- SHEET METAL SCREWS

#### **GROUND LOOP**

- ¾" PE PIPE
- 1-1/4" PE PIPE
- PE PIPE FITTINGS
- 1" CLEAR HOSE (HEAT PUMP TO PUMP PACK)
- HOSE CLAMPS
- ANTIFREEZE: METHANOL OR PROP. GLYCOL

#### **ELECTRICAL**

- HEAT PUMP SERVICE WIRE: 14-2 OR 12-2
- PLENUM HEATER SERVICE WIRE
- HEAT PUMP BREAKERPLENUM HEATER BREAKER
- THERMOSTAT WIRE 18-8
- THERMOSTAT WIRE 18-2 (PLENUM HEATER)
- FORK TERMINALS FOR TSTAT WIRE (10)
- CONDENSATE PUMP & HOSE (IF REQUIRED)
- 2" STYROFOAM INSUL. (IF PAD NOT PURCHASED)

right, or back sides. Raising the indoor unit off the floor a few inches is generally a good practice since this will prevent rusting of the bottom panel of the unit from concrete floors, and deaden vibrations. An anti-vibration pad, available as an accessory, or a piece of 2" styrofoam should be placed under the unit.

Horizontal **RH**-series units are normally mounted in a concealed ceiling, and securely hung using the built-in hangers (or floor mounted in a crawl space). The front access panel, the access panel opposite the air return, and the access panel on the end or side which is the same size as the fan discharge panel should remain clear of obstruction for a distance of 2 ft (0.7 m) to facilitate servicing and general maintenance.

For both **R** and **RH** units, ensure the unit is level to eliminate condensate draining issues.

The heat pump comes equipped with an air filter rack which can be installed with the removable end (where the filter is inserted) on either side to facilitate changing the filter. Be careful not to run piping in front of the filter rack access cover, since access is required in order to change the air filter.

#### Sample Bill of Materials -Open/Building Loop Installations

#### FROM MARITIME GEOTHERMAL

- R/RH SERIES HEAT PUMP (L OR R RETURN)
- PLENUM HEATER 5/7kW
- 2H/1C THERMOSTAT (OR SOURCED ELSEWHERE)
- P/T PORTS AND HOSE ADAPTERS (2)
- DOLE/HAYS FLOW RESTRICTOR VALVE
- SOLENOID OR MOTORIZED WATER VALVE

#### **OPTIONAL FROM MARITIME GEOTHERMAL**

- ANTI-VIBRATION PAD
- SOUND JACKET

#### DUCTWORK

- OUTLET PLENUM ADAPTER W/ FLEXIBLE COLLAR
- RETURN AIR ADAPTER W/ FLEXIBLE COLLAR
- FIBREGLASS INSULATION (FOR NOISE, IF REQ'D)
- TRUNK DUCT W/ JOINERS (IF NOT EXISTING)
- 6" ROUND DUCT W/ ADAPTERS (IF NOT EXISTING)
- ALUMINUM TAPE
- SHEET METAL SCREWS

#### WATER SYSTEM (OPEN LOOP ONLY)

- 1" BLACK PLASTIC WATER PIPE
- 1" BARBED FITTINGS & HOSE CLAMPS
- VSP SUBMERSIBLE PUMP (IF NOT EXISTING)
- PRESSURE TANK (IF NOT EXISTING)
- CYCLE STOP VALVE (IF FIXED SPEED PUMP)

#### **ELECTRICAL**

- HEAT PUMP SERVICE WIRE: 14-2 OR 12-2
- PLENUM HEATER SERVICE WIRE
- HEAT PUMP BREAKER
- PLENUM HEATER BREAKER
- THERMOSTAT WIRE 18-8
- THERMOSTAT WIRE 18-2 (PLENUM HEATER)
- FORK TERMINALS FOR TSTAT WIRE (10)
  CONDENSATE PUMP & HOSE (IF REQUIRED)
- CONDENSATE PUMP & HOSE (IF REQUIRED)
- 2" STYROFOAM INSUL. (IF PAD NOT PURCHASED)

## **Air Outlet Orientation**

For vertical **R**-series units, the air discharge location is in a fixed position, blowing upwards.

For horizontal **RH**-series units, as is typical for heat pumps of this type, the air discharge can be field installed in either the side (default position, opposite the air return) or the end (90° to the air return). To switch it to the end position, before ductwork is installed:

- 1. Ensure power to the unit is off.
- 2. Remove the screws that hold the access panel adjacent to the blower panel in place and remove the access panel by pulling up on the handle and then outward from the bottom.
- 3. Repeat for the access panel with the blower mounted in it. Ensure the wiring harnesses move freely while removing the blower.
- 4. Disconnect the wiring harness plugs from the motor, and the ground wire from the fan housing.
- Place the blower in front of its new 'end' location, making sure the motor is facing toward the adjacent access panel. Flip the blower and panel over if required. Reconnect both motor plugs and the housing ground wire.
- 6. Install the blower and secure panel with the screws.
- 7. Install the adjacent access panel and secure with the remaining screws.

Note for both **R** and **RH** units, for blower motor servicing the entire blower can be removed out the adjacent access panel by removing two bolts:





## Air Return Orientation

The heat pump can be ordered as left or right air return from the factory. This must be specified at time of order as the physical construction of the two configurations is different. Refer to the **Dimensions** section toward the end of this manual for physical dimensions of the units.



LEFT RETURN

RIGHT RETURN

## **Plenum Heater Installation (Optional)**

Be sure to order the 'internally mounted' type of plenum heater, since the plenum heater intended for external installation in larger heat pumps has a cage which is too wide for the smaller ductwork used with these smaller heat pumps.

Plenum heater should be installed in the air discharge duct outside the heat pump cabinet in a manner that allows all of the airflow to pass through it to prevent any hot spots in the heater elements. Ensure that the plenum heater is mounted in an approved position as per its instructions. (If there is an airflow direction arrow on the plenum heater, it can be disregarded.)

# Wiring

### **Power Supply Connections**

The heat pump has a 0.875" knockout for main power supply connection from the breaker panel to the electrical box. There are also 0.875" knockouts and a plastic grommet for connections to plenum heater power supply, thermostat, and water valve or ground loop pump pack.

#### NOTE: Two separate power supplies are required, one for the heat pump and a second one for the plenum heater. Each must have its own supply wires and breaker.

Electrical diagram can be found on the electrical box cover as well as in the **Model Specific Information** section of this manual. The Electrical Tables in the **Model Specific Information** section contain information about the wire and breaker



NOTE: A properly qualified electrician should be retained for all connections to the heat pump and associated controls. The connections to the unit MUST CONFORM TO LOCAL CODES.

TABLE 4 - Power Supply Connections (Heat Pump)				
Line	Description Voltages			
L1	Line 1	208/230-1-60, 277-1-60		
L2	Line 2	208/230-1-60, 277-1-60		
GND	Ground	208/230-1-60, 277-1-60		
N Neutral No Connection				

TABLE 5 - Power Supply Connections (Plenum Heater)				
Line	Description	Voltages		
L1	Line 1	All		
L2	Line 2	All		
GND	Ground	All (connect to ground lug)		
N	Neutral	No Connection		

#### Outdoor Loop Pump Module Wiring (Ground Loop, or Single Pipe Building Loop)

The circulator pump or pump module should be wired so that they will be turned on whenever the compressor operates.

Unlike other NORDIC model series, there is no dedicated terminal strip for circulator pump connection in the heat pump, and there is no neutral wire connection to the heat pump to allow 115v circulators to be powered from the heat pump. Circulators may be externally powered and controlled, using a relay or contactor activated by the **Y** signal from the thermostat.

However, 230v circulators may be connected to the load side of the heat pump's compressor contactor using ring terminals or female disconnects, as long as they do not exceed **1.5A** maximum current draw. Ground wire should be connected to the ground lug in the electrical box.

### **Control Transformer**

The low voltage controls for 208/230-1-60 models are powered by a class II transformer with impedance protection. If the 24v side is accidentally shorted out and impedance protection is tripped, it will be necessary to replace the transformer.

NOMENCLATURE CODE "1L" - red wire is factory set to 230V NOMENCLATURE CODE "9L" - red wire is factory set to 208V



IMPORTANT NOTE: Red wire may be switched between 208VAC and 230VAC terminals on transformer at customer location to suit local electrical service type. If not set correctly, controls and accessories may not work properly.

#### **Thermostat Requirements**

A 2-stage heating and 1-stage cooling heat pump configurable thermostat is required. The first thermostat heating stage activates the compressor by sending a **Y** signal, and the second activates the electric auxiliary (accessory plenum heater) by sending a **W**<sub>2</sub> signal. The electrical diagram on the electrical box cover provides a description of the signal connections, as does the below table. Refer to diagram on a following page for connections between the thermostat and the heat pump.

Cooling mode is activated by the thermostat by sending an **O** signal, along with a **Y** signal to activate the compressor.

TABLE 6 - Control Signal Description				
Signal	Description			
С	24VAC common (ground)			
G	Fan lowest speed (for air recirculation)			
R	24VAC hot			
L	Fault (24VAC when fault condition)			
0	Cooling mode (reversing valve)			
Y	Compressor ON			
W <sub>2</sub>	Auxiliary / Emergency Heat			
C(I)	Plenum heater dry contact (Connect to C or I in plenum heater)			
1	Plenum heater dry contact (Connect to 1 and 2 in plenum heater)			

#### **Blower Motor**

The blower is equipped with a 5-speed (actually 5 constant torque) direct drive ECM. The motor features a soft start which provides a smooth, quiet ramp up to operating speed.

The lowest speed is activated by a G signal from the thermostat, used for air recirculation or fan only mode. There are 4 speeds associated with compressor operation, one of which should be selected during heat pump commissioning.

Move the fork terminal with the yellow and purple wire to one of the terminals  $SP_1 / SP_2 / SP_3 / SP_4$ . Measure the airflow in the discharge ductwork and select a speed that most closely matches the required airflow for the model size according to the following table. Proper airflow can be verified by observing the air delta T, which should be 25-32°F. Assuming a room temperature of 68°F, compressor discharge pressure at proper airflow should be 320-400 psi.

If too low an airflow is selected, heat pump efficiency will be lower and nuisance high or low safety control trips may oc-

cur. Too high an airflow will result in excessive noise and a cooler discharge air temperature. If the target airflow cannot be achieved even on  $\mathbf{SP}_4$ , the ductwork is likely undersized and ductwork design should be reviewed as per following chapter.

TABLE 7 - Airflow			
Model	Required Airflow		
R/RH-09	325		
R/RH-12	400		
R/RH-18	650		
R/RH-24	800		

## **Safety Controls**

The heat pump has two important built in safety controls which are designed to protect the unit from situations which could damage it should the operation of the refrigeration circuit fall outside the allowable operating range.

#### 1. High Pressure Control

The high pressure safety control monitors the compressor discharge pressure and will shut the compressor down if the condensing pressure becomes too high.

There are (3) main reasons this control would activate in response to the operating conditions of the unit while operating in heating mode:

- 1. Low or no indoor loop flow.
- 2. High indoor loop entering liquid temperature.
- 3. Dirty or fouled indoor loop heat exchanger.
- 4. High refrigerant charge after service, or mechanical malfunction (see **Troubleshooting** section).

#### 2. Low Pressure Control

The low pressure control monitors the compressor suction pressure and will shut the compressor down if the refrigerant evaporating pressure becomes too low, risking the danger of freezing conditions in the evaporator.

There are (3) main reasons this control would activate in response to the operating conditions of the unit while operating in heating mode:

- 1. Low or no outdoor loop flow.
- 2. Low outdoor loop entering liquid temperature.
- 3. Dirty or fouled outdoor loop heat exchanger.
- 4. Low refrigerant charge due to leak, or mechanical malfunction (see **Troubleshooting** section).

The unit contains a control board that monitors the safety controls and operates the compressor accordingly. The low pressure control and high pressure controls are connected to the control board as shown on the wiring diagram later in this manual.

The compressor will not be allowed to start if a 'fault' condition exists. A 'fault' occurs if either one of the pressure controls exhibits an open circuit. In addition, the board monitors a condensate overflow sensor, located in the drip tray, and the voltage of the 24vac transformer. A fault will occur if a condensate overflow is detected, or a low voltage condition (electricity grid brownout) is detected.

The control board has an on-board LED and an ALR pin with a 24VAC output, which is routed to the L terminal of the thermostat terminal strip. An external indicator or relay can be connected across L and C on the terminal strip if external signaling is desired. Should a fault condition occur, the LED will flash the code of the fault condition. The codes are shown in the following table. The control board will lock out the compressor for five minutes when a fault occurs. The control board will then restart the compressor if the fault has been cleared. Should a second fault condition occur within a 60 minute period the control board will go into permanent lockout mode and energize the ALR pin. The LED will flash the fault code until the control board is reset by powering down the unit.

The board has a **TEST** jumper, which defeats the 5 minute anti-short cycle timer for test purposes. If left in the TEST position, it will time out and return to normal operation after a set time period. This is to prevent compressor short cycling and possible damage or shortened lifespan if the jumper is accidentally left in the TEST position.

There are also **FREEZE TEMP** and **WATER TEMP** jumpers on the control board. Under standard heat pump configurations, **these are not used and have no effect on heat pump operation**.

#### TABLE 8 - Control Board Fault Codes

Fault	LED Flashes			
High Pressure	1			
Low Pressure	2			
Condensate Overflow	4			
Brownout	5			

## **Open/Closed Loop LPC Selection**

There are two low pressure controls (LPC's) in the heat pump: 75 psi for building loop or open loop (fresh water), and 55 psi for closed loop (antifreeze). As shipped, the open loop LPC will be active, since there will be no jumper between  $LP_1$  and  $LP_2$  on the heat pump's terminal strip.

If a closed ground loop with antifreeze is used, a wire jumper should be installed between  $LP_1$  and  $LP_2$  on the heat pump's terminal strip. This will cause the lower 55 psi low pressure control to be selected, to allow a lower loop temperature than would be appropriate for fresh water before tripping.



WARNING: WHEN LP1 AND LP2 ARE JUMPERED, A PROPER LOOP ANTIFREEZE CONCENTRATION IS REQUIRED TO PREVENT FREEZING AND RUPTURING OF THE HEAT EXCHANGER, VOIDING THE WARRANTY.

# Piping

### **Condensate Drain**

The unit comes equipped with one 3/4" female PVC socket or 3/4" PVC female NPT drain connection. This drain allows the condensate which forms during the air conditioning cycle to be removed from the unit. The drain should be connected and vented as per local codes. During high humidity weather, there could be as much as 25 gallons of water formed per day.

For vertical **R** units, the condensate drain is internally trapped and does not require an external trap. For horizontal **RH** units, the condensate drain is **not** internally trapped, and an external trap and vent must be installed.

An external condensate pump may be installed if there is not sufficient drain piping slope possible to drain condensate under gravity to its destination.

To avoid overflow of the condensate pan, the drain line and trap should be inspected periodically to ensure they are not plugged with accumulated debris.

There is an alarm for condensate overflow, which will disable unit operation.

See following pages for diagrams showing the condensate drain connection.

## **Outdoor Loop**

The connections for the Outdoor Loop are 1/2" or 3/4" brass female NPT. They are labelled OUTDOOR IN and OUTDOOR OUT.

See the following page for an illustration of a building loop installation, and also the following chapters for details on ground loop and open loop installations.



See other diagrams and instructions in the manual for design, selection, and installation details. Many of the items illustrated in this diagram are available as accessories from Maritime Geothermal Ltd.. Other items are commonly available from plumbing or HVAC wholesalers.

This diagram illustrates the use of an externally conditioned building loop as a heat source (heating mode) or heat sink (cooling mode). Piping will differ for:

- Open loop installation, which uses a well water system in place of a closed building loop.

- Ground loop installation, which uses a horizontal or vertical antifreeze loop in the ground as a heat source/sink.

See manual for details.

					Drawn By Dan Rheault	5-May-2021	MADITIME CENTHERMAL ITD P.O. Box 2555 170 Plantation Rd.
					Checked By Dan Rheault	Date 5-May-2021	MANITIWE OLUTTILITIVIAL LID. Petitcodiac, NB CANADA E4Z 6H4
					Eng. Approved By	Date	Drawing Name
					Elig. Approved by	Dute	Typical Loop Connections -
					Mfg. Approved By	Date	Commercial R/RH Series
01	Initial Rel.	Dan Rheault	Dan Rheault	5-May-2021	Approved By	Date	Size Drawing Number Revision Sheet
REV	ECO#	IMPL BY	APVD BY	DATE			LET 002513PDG 01 1/1

## **Ductwork**

#### **Blower Motor**

The indoor unit is equipped with a direct drive 5-speed ECM blower. See Wiring chapter for description and airflow adjustment.

## **Duct Systems - General**

Ductwork layout for a heat pump will differ from traditional hot air furnace design in the number of leads and size of main trunks required. Air temperature leaving the heat pump is normally **95° -105°F (35-40°C)**, much cooler than that of a conventional fossil fuel furnace. To compensate for this, larger volumes of lower temperature air must be moved and consequently duct sizing must be able to accommodate the greater airflow without creating a high static pressure or high velocity at the floor diffusers.

A duct system capable of supplying the required airflow is of utmost importance. Maritime Geothermal Ltd. recommends that the external static pressure from the duct system be kept below 0.2 inches of water total. In some instances the number of floor diffusers will actually double when compared to the number that would be used for a hot air oil-fired furnace. Refer to following tables.

- 1. Generally allow 100 cfm for each floor grill.
- 2. All leads to the grills should be 6" in diameter (28sq.in. each).
- 3. The main hot air trunks should be at least 75% of the square surface area of leads being fed at any given point.
- 4. Return air grills should have a minimum of the same total cross sectional area as the total of the supply grills.
- The cross sectional area of the return trunks should equal the cross sectional area of the grills being handled at any given point along the trunk.

It is **VERY IMPORTANT** that all turns in both the supply trunks and the return trunks be made with **TURNING RADII**. Air act like a fluid and, just like water, pressure drop is increased when air is forced to change direction rapidly around a sharp or irregular corner.

It is recommended that flexible collars be used to connect the main trunks to the heat pump. This helps prevent any vibrations from travelling down the ductwork. If a plenum heater is installed, the collar should be at least 12" away from the heater elements.

If desired, the first 5-10 feet of the main supply trunks can be insulated internally with acoustical duct insulation to further inhibit any noise from the unit from travelling down the ductwork. If a plenum heater is installed, insulation should not be placed within 12" of the heater elements.

#### **Duct Systems - Grill Layout**

Most forced air heating systems have the floor grills placed around the perimeter of the room. Supply grills should be placed under a window when possible to help prevent condensation on the window. As mentioned in the previous subsection, supply grill leads should be 6" in diameter (28 square inches each) to allow **100 cfm** of airflow.

In a typical new construction, there should be one supply grill for every 100 square feet of area in the room. When rooms require more than one grill, they should be placed in a manner that promotes even heat distribution, such as one at each end of the room. It is always a good idea to place a damper in each grill supply or place adjustable grills so that any imbalances in the heat distribution can be corrected.

The total number of supply grills available is based on the heat pump nominal airflow. The table shows the number of grills recommended per heat pump size.

TABLE 9 - Heat Pump Size vs. Hot Air Grills						
Model	# of Grills (@100 cfm)					
09	0.75	3				
12	1	4				
18	1.5	6				
24	2	8				

Return grills should be mounted on the floor. At minimum they should be the same size as the supply grill, it is highly recommended that they be 25% to 50% larger than the total supply. They should be placed opposite the supply grills when possible to ensure distribution across the room. For rooms requiring more than one supply grill, it may be possible to use one larger return grill if it can be centrally positioned opposite of the supply grills, however it is preferred to have one return for each supply to optimize heat distribution across the room.

#### **Thermostat Location**

Most small installations are a single ducted air zone with one thermostat. The thermostat should be centrally located within the space, typically on the main floor. It should be placed away from any supply grills, and should not be positioned directly above a return grill. The thermostat can be located in a hallway, or on the inner wall of a room. It should be noted that most buildings not have any supply ducts in the hallway. This can lead to a temperature lag at the thermostat if there is very little air movement in the hallway, causing the space to be warmer than indicated by the thermostat.

#### **Plenum Heater**

As described in the **Installation Basics** section, the plenum heater will be installed in the discharge ductwork outside the unit, at least 12" away from any flexible duct collars. There is an accessory plenum heater with a wider cage profile available that is more suitable for duct installation than the model with the narrower cage which is meant for internal installation in larger heat pumps.



TABLE 1	TABLE 10 - Duct Sizing Guide (external static of 0.20" H <sub>2</sub> O)									
Airflow (CFM)	Minimum Duct Area (sq.in)	Diameter (in)		Rect	angular E	quivalent	s (in)		Return Air Diameter (in)	Airflow (L/s)
37	20	5	2.25 x 10	3 x 8	3.5 x 6	4 x 5.5	5 x 5	``	<b></b> 5	17
63	20	5	2.25 x 10	3 x 8	3.5 x 6	4 x 5.5	5 x 5		6	30
100	28	6	3.25 x 10	4 x 8	5 x 6	5.5 x 5.5	6 x 6		۲ <b>ر</b>	47
152	38	7	3.25 x 14	4 x 11	5 x 8.5	6 x 7	6.5 x 6.5		8	72
212	50	8	4 x 15	5 x 12	6 x 10	7 x 8	8 x 8		9 – 9	100
226	50	8	4 x 15	5 x 12	6 x 10	7 x 8	8 x 8		10	107
277	64	9	5 x 15	6 x 12	7 x 10	8 x 9	8.5 x 8.5		<b>-</b> 10	131
304	64	9	5 x 15	6 x 12	7 x 10	8 x 9	8.5 x 8.5			143
393	79	10	6 x 15	7 x 13	8 x 11	9 x 10	9.5 x 9.5		<b>-</b> 12	185
411	113	12	7 x 18	8 x 16	9 x 14	10 x 12	11 x 11		<b>4</b> 12	194
655	113	12	7 x 18	8 x 16	9 x 14	10 x 12	11 x 11		<b>□</b> <sup>14</sup>	309
680	154	14	8 x 22	9 x 19	10 x 17	11 x 15	12 x 14	13 x 13	<b>4</b> 14	321
995	154	14	8 x 22	9 x 19	10 x 17	11 x 15	12 x 14	13 x 13	<b>−</b> <sup>16</sup>	470
1325	201	16	8 x 30	10 x 22	12 x 18	14 x 16	15 x 15			625
1450	201	16	8 x 30	10 x 22	12 x 18	14 x 16	15 x 15			684
1750	254	18	8 x 40	10 x 30	12 x 24	14 x 20	16 x 17	16.5 x 16.5	<b>↓</b> 20	826
2000	254	18	8 x 40	10 x 30	12 x 24	14 x 20	16 x 17	16.5 x 16.5	Γ <sup>22</sup>	944
2250	314	20	10 x 38	12 x 30	14 x 26	16 x 22	18 x 19	18.5 x 18.5	<b>↓</b> – 22	1062
2600	314	20	10 x 38	12 x 30	14 x 26	16 x 22	18 x 19	18.5 x 18.5	<b>–</b> <sup>24</sup>	1227
2900	380	22	12 x 36	14 x 30	16 x 26	18 x 23	20 x 20		<b>↓</b> 24	1369
3400	380	22	12 x 36	14 x 30	16 x 26	18 x 23	20 x 20		<b>1</b> <sup>-26</sup>	1605
3600	452	24	14 x 38	16 x 32	18 x 28	20 x 25	22 x 22		<b>→ /</b> <del>-</del> 26	1699
4300	452	24	14 x 38	16 x 32	18 x 28	20 x 25	22 x 22		<sup>28</sup>	2029
5250	531	26	16 x 38	18 x 32	20 x 30	22 x 24	24 x 24			2478
6125	616	28	18 x 38	20 x 34	22 x 30	24 x 28	26 x 26			2891
6500	616	28	18 x 38	20 x 34	22 x 30	24 x 28	26 x 26			3068
7250	707	30	20 x 40	22 x 38	24 x 32	26 x 30	28 x 28		<b>1 -</b> 34	3422
7800	707	30	20 x 40	22 x 38	24 x 32	26 x 30	28 x 28			3681
8500	804	32	22 x 40	24 x 38	26 x 34	28 x 32	30 x 30		/ <del>-</del> 36	4012
9200	804	32	22 x 40	24 x 38	26 x 34	28 x 32	30 x 30			4342
9800	908	34	24 x 42	25 x 40	26 x 38	28 x 34	30 x 32	31 x 31	-38	4625
10900	908	34	24 x 42	25 x 40	26 x 38	28 x 34	30 x 32	31 x 31	40	5144
			28 x 40	30 x 36	32 x 34	33 x 33			<b>≁</b> ″	
			30 x 42	32 x 38	34 x 36	35 x 35			<b>↓</b> /	
			30 x 45	34 x 40	36 x 38	37 x 37				

# **Ground Loop Installations**

Refer to diagrams **000608INF** & **000609INF** at the end of this section for typical ground loop configurations. They are for reference only, and should not be used to replace formal training and computerized loop design.

Once the ground loop has been pressure tested and the header pipes have been connected to the circulator pump module, the heat pump can be connected to the circulator pump module.

## **Circulator Pump Module**

Maritime Geothermal Ltd. offers compact pump modules with built in three way valves to facilitate filling and purging the ground loop. Refer to drawing **000906CDG** at the end of this section. Alternatively, Grundfoss Model UPS 26-99 or Taco Model 0011 pumps or other brands with similar pumping capability may be used. The single pump module will typically handle systems up to 3 tons. This is based on a typical parallel system with one circuit per ton.

Calculate the total pressure drop of the ground loop (including headers, indoor piping and heat pump exchanger drop) based on the antifreeze type and concentration at the desired minimum loop temperature. A pump module that can deliver the flow required for the unit at the calculated total pressure drop should be selected. Refer to the **Model Specific Information** section for unit flow requirements. Loop pressure drops can be calculated using software such as those mentioned in the Horizontal Ground loops section, or can be calculated in a spreadsheet using the pipe manufacturer's pressure drop tables for pipe diameter and fittings.

The circulator pump module must be connected to the heat pump Outdoor Loop ports with a lineset suitable for the flow required with minimum pressure drop. 1" rubber or plastic lines should be used.

The installation of P/T plugs/ports (pressure / temperature, pronounced "*Pete's plugs*") is recommended on both the entering and leaving lines at the heat pump. This will allow the installer or homeowner to check water flow through the loop by measuring the pressure difference through the heat exchanger and comparing it to that listed in the **Model Specific Information** section. P/T ports, adapters, and gauge adapters and are available as accessories from Maritime Geothermal Ltd.

## **Flushing & Purging**

Once the groundloop has been installed and all connections are completed between the heat pump, circulator pump module and ground loop, the entire ground loop system should be **pressure tested with air to 100 PSIG** to make sure there are no leaks on any of the inside fittings. Soap all joints and observe that the pressure remains constant for 1 hour.

When satisfied that all connections are leak free, release the air pressure and connect a purge cart (see **Figure 1**) to the flushing access ports at the pump module (refer to drawing **000906CDG**). A temporary flushing system can alternately be constructed using a 45 gal. barrel and a pump with sufficient volume and head capability to circulate fluid at a **velocity of at least 2 ft/min** through all parts of the loop.

Adjust the circulator pump module valves to connect the purge cart to the ground loop. Begin pumping water through the ground loop, ensuring that the intake of the pump stays submerged at all times by continuously adding water. Water flowing back from the return line should be directed below the water level in the barrel or flush tank to prevent air being mixed with the outgoing water. Once the lines have been filled and no more air bubbles are appearing in the line, adjust the circulator pump module valves to circulate water through the heat pump using the same technique as described above. When all air is removed reverse the flow of water through the lines by interchanging the flush cart lines and purge again. You will be able to visibly tell when all air is removed.



## **Adding Antifreeze Solution**

In most mid and northern areas of the US and in all of Canada it is necessary to condition the loop fluid by the addition of some type of antifreeze solution so that it will not freeze during operation in the winter months. This antifreeze is required because the loop fluid will normally reach a low entering temperature of 28°F to 32°F (-2°C to 0°C) and refrigerant temperatures inside the heat pump's heat exchanger may be as low as 20°F (11°C) cooler. See following table for details of freeze protection provided by different concentrations.

TABLE 11 - Antifreeze Percentages								
BY VOLUME								
Protection to: 10°F 15°F 20°F 25°F								
Methanol	25%	21%	16%	10%				
Propylene Glycol	Propylene Glycol         38%         30%         22%         15%							
BY WEIGHT								
Protection to:	10°F	15°F	20°F	25°F				
Methanol	Methanol 16.8% 13.6% 10% 6.3%							
Propylene Glycol	30%	23.5%	18.3%	12.9%				



WARNING: Add enough antifreeze to allow for a temperature 20°F (11°C) lower than the expected lowest loop fluid temperature entering the heat pump. Insufficient antifreeze concentration could cause the heat exchanger to freeze and rupture, voiding the warranty.

Although many different antifreeze solutions have been employed in geothermal systems, the alcohols such as methanol or ethanol have the most desirable characteristics for groundloop applications. The overall heat transfer characteristics of these fluids remain high although care must be taken when handling pure alcohols since they are extremely flammable. Once mixed in a typical 25% by volume ratio with water the solution is not flammable. In situations where alcohols are not allowed as a loop fluid due to local regulations then propylene glycol is a non-toxic alternative which can be substituted . Propylene glycol should only be used in cases where alcohols are not permitted since the heat transfer characteristics are less desirable and it becomes more viscous at low temperatures, increasing pumping power.

The volume of fluid that your loop system holds can be closely estimated by totaling the number of ft. of each size pipe in the system and referencing the following table for approximate volume per 100 ft.

When the volume of the loop has been calculated and the appropriate amount of antifreeze is ready for addition by referencing the table, drain the equivalent amount of water from the flush cart or mixing barrel and replace it with the antifreeze.

When using alcohols, be sure to inject below the water line to reduce initial volatility of the pure antifreeze. If the loop is large it may be necessary to refill the tank with antifreeze several times to get all the antifreeze into the loop. Pump the loop for 5 to 10 minutes longer to ensure the remaining fluid has been well mixed.

### **Initial Pressurization**

At this point open all valves in the flow circuit and slowly close off the supply and return flush cart valves in a manner that leaves about **20-30 psig**. on the system. If an air bladder expansion tank is used it should be charged to the above

TABLE 12 - Volume of fluid per 100 ft. of pipe								
		Vol	ume /100	Oft.				
Type of Pipe	Diameter	l.gal	gal	L				
Copper	1"	3.4	4.1	15.5				
	1-1/4"	5.3	6.4	24.2				
	1-1/2"	7.7	9.2	34.8				
Rubber Hose	1"	3.2	3.9	14.8				
Polyethylene	3/4" IPS SDR11	2.3	2.8	10.6				
	1" IPS SDR11	3.7	4.5	17.0				
	1-1/4" IPS SDR11	6.7	8.0	30.3				
	1-1/2" IPS SDR11	9.1	10.9	41.3				
	2" IPS SDR11	15.0	18.0	68.1				
	Other Item Volur	nes	• -	-				
Heat Exchanger	Average	1.2	1.5	5.7				
Purge Cart Tank	See cart manual		TBD					

pressure before actual water pressure is put on the system . Systems without an expansion tank will experience greater fluctuations in pressure between the heating and cooling seasons, causing pressure gauges to have different values as the loop temperature changes. This fluctuation is normal since expansion and contraction of the loop fluid must be handled by the elasticity of the plastic loop.

- Pressurize the loop to a static pressure of 45 psig. when installing a system in the fall going into the heating season.
- Pressurize the loop to a static pressure of **25 psig**. when installing a system in the spring or summer going into the cooling season.

After operating the heat pump for a period of time, any residual air in the system should be bled off and the static pressure should be verified and adjusted if necessary. Add additional water / antifreeze mix with the purge cart to bring the pressure back to the original setting if required.

## **Pipe Insulation**

All ground loop piping inside the structure (between the structure entry point and the heat pump) should be insulated with 3/8" thick closed cell pipe insulation to prevent condensation and dripping onto floors or walls.

## **Low Pressure Control Selection**

The purpose of the low pressure control is prevent heat exchanger freezing in the case of a flow problem.

Unlike other NORDIC model series, low pressure control selection for open loop for the R/RH 09-24 is done manually, with a wire jumper. For closed loops with antifreeze, make sure a jumper is connected between **LP1** and **LP2** on the heat pump's terminal strip. This will cause the lower 55 psi low pressure control to be selected, to allow a lower loop temperature than would be appropriate for fresh water before tripping.



go to TABLE OF CONTENTS



SHEET

1 of 1



	`~										
					Drawn By Chris Geddes	Date 09 DEC 08	M	ARITIME G	<b>ΕΩΤΗΕΒΜΔΙ</b>	170 ITN Petito	Plantation Rd. codiac, NB
					Checked By Chris Geddes	Date 09 DEC 08	IVI		LUTITLIINIAL	LID. E4Z	6H4
03	000264	D. RHEAULT	D. RHEAULT	21-Aug-2018	Approved By (ENG	) Date	Drawing	g Name Ge	eo-Flo Circulator	Pump Mod	ule
02	000213	C. GEDDES	C. GEDDES	21-May-2013	Chris Geddes Approved By (MFG	09 DEC 08			Installation (Bra	ass FPT)	
01	Initial Release	C. GEDDES	C. GEDDES	9-Dec-2008	Arrent Di	Dete	Size	Drawing Numb	er	Drawing Rev	SHEET
REV	ECO #	IMPL BY	APVD BY	DATE	Approved By	Date	A	(	000906PDG	03	1 of 1



#### NOTES:

- Circulator Pump Module should be mounted vertically to minimize the possibility of air locking the circulators.
- All lines inside the structure and through the wall should be insualted with 3/8" to 1/2" thick closed cell pipe insulation.
- Holes through the foundation / structure should be filled with expanding foam from both sides to prevent leakage.
- Proper drainage material should be used on the outside of the wall to prevent water buildup.
- Pump module fittings are available from Maritime Geothermal Ltd.
- A pressure gauge is recommended if P/T plugs are not installed.
- For most applications, a 1 pump module will accomodate model sizes 09 to 45, and a 2 pump module will accomodate sizes 55 to 80. The total loop pressure drop including the headers, inside piping and heat exchanger drop should be calculated based on the antifreeze mixture and lowest desired entering water temperature. The pump module selected must provide the required flow at this calculated pressure drop value.



#### Well Water Temperature

The temperature of the well water should be a minimum of  $41^{\circ}F$  (5°C), and should normally be  $45^{\circ}F+$  (7°C+). In general, groundwater temperatures across the Canadian prairie provinces and Northern Ontario may be close to the  $41^{\circ}F$  minimum, while in other parts of southern Canada it will probably be 46-50°F, although local exceptions will exist. In more southern locations, it will be warmer.

The well water temperature should be verified as the first step in a proposed open loop installation.

#### **Well Water Flow**

The water source is normally a drilled water well with submersible pump that is the same well which supplies domestic water needs. It must be able to supply the required water flow as listed under the Total Flow column in the table.

TABLE 13 - Required Flow								
Model SizeFlow* gpm (L/s)Domestic Water Usage - gpm (L/s)Total Flow gpm (L/s)								
09 2.5 (0.16) 4 (0.25) 6.5 (0.43)								
12	12 3.0 (0.20) 4 (0.25) 7.0 (0.46)							
18	4.5 (0.28)	4 (0.25)	8.5 (0.54)					
24	24 8.0 (0.50) 4 (0.25) 12 (0.76)							
* These enter	* These are minimum water requirements based on an entering water temperature of 45° F.							

For groundwater temperatures of  $50^{\circ}$ F or greater, these flows can be reduced by 25% if required.

Rather than being estimated by a well driller, the flow from a proposed source well should be measured by performing an extended flow test to be sure it is capable of supplying the required flow over an extended period of time. This is done by flowing the well at the highest possible rate, noting the static water level in the well, and monitoring the pumping fluid level until stable. Unless the fluid level is very high, fluid level monitoring will require a device called a water level sounder. The flow rate can then be measured either by a cumulative gallon meter, a flowmeter, or by timing the filling of a bucket of known size. The test data can be recorded as follows:

TIME	METER READING (USGAL)	TOTAL FLOW (USGAL)	FLOW RATE (USGPM)	WATER LEVEL (FT)	(IN)	WATER LEVEL (FT)
20:25	131735.5	0		20	6	20.5
20:27	131756	20.5	10.3	24	0	24.0
20:30	131779	23	6.0	26	0	26.0
20:42	131847	68	6.1	29	0	29.0
20:51	131906	59	6.6	29	0	29.0
21:03	131982	76	6.3	29	0	29.0
21:32	132156	174	6.0	29	0	29.0

It is best to flow the well for as long as possible (e.g. 12 hours) at the flow rate required by the proposed heat pump size. However, if the test is performed before a larger submersible pump is installed, it may be assumed that any unused water level drop during the test (that is, any distance remaining between the pumping fluid level and the pump intake) would contribute linearly to the flow rate should a larger pump be installed.

In the above example, it was recorded that the flow rate stabilized at 6 gpm, while the water level dropped from 20 to 29

feet (9 feet). If the intake of a larger pump could be placed so that a further pumping fluid level drop of 9 feet could be achieved (total 18 feet), it can be assumed that the flow would double to 12 gpm. Of course, this should be verified with a second test once the larger pump is actually installed.

## **Well Water Quality**

The well water should be tested to be sure it meets minimum standards. Although the threat of poor water quality to open loop installations is often exaggerated, poor water quality can lead to rapid heat exchanger failure or frequent servicing.

First, the well should not produce any sand. Sand will physically erode heat exchanger surfaces, and quickly clog return (injection) wells. **Solids** or **TDS** should be less than **1 ppm** (**1 mg/L**) if a return well is used.

To avoid scale formation on the inside of the heat pump's outdoor loop coil, total **hardness** should be less than **350 ppm / 350 mg/L**. In practice, scaling is very rarely a problem at northern groundwater temperatures of 50°F or less because scale does not generally form at low well water temperatures (unlike, for example, in a domestic hot water tank). In more southern climates, the hardness guideline will be a more important consideration. Should scale form, heat pump performance will gradually deteriorate, and will require periodic flushing with a calcium/lime removing solution (see General Maintenance section). If the need for periodic flushing is anticipated, the optional Cupro-Nickel (CuNi) coil and piping should be ordered.

Corrosive (salty) water can cause failure of the inner tube of the heat exchanger, leading to loss of refrigerant and water entering the refrigeration circuit, which ruins the heat pump. If **chlorides** exceed **20 ppm (20 mg/L)**, the optional CuNi coil and piping should be ordered. If chlorides exceed **150 ppm (150 mg/L)**, or significant **Ammonia (>0.5 ppm)** or H<sub>2</sub>S (>0.2 ppm) is present, the use of an open loop system should be reconsidered.

## **Water Discharge Methods**

Water disposal methods vary from area to area. However, some consideration should be made to prevent the cooled discharge water from immediately coming in contact with the supply source. Attempting to return the water to the source well will eventually cool the water so much that the heat pump will shut off on its low pressure safety control.

Acceptable methods for disposing of the waste water are listed below. The waste water is clean; the heat pump has no effect other than reducing the temperature of the water. Refer to diagram on following page for typical disposal method diagrams.

- Second well (return well)
- Percolation (Drain, ditch, leaching field)
- Pond, river or stream

#### ENSURE SELECTED METHOD CONFORMS TO LOCAL REGULATIONS.

A return well should be a minimum of **80 ft**. from the supply well for residential applications. The water returned to the well will not necessarily be pumped into the same aquifer, depending on underground conditions. The return well must be able to supply at least the same quantity of water as the amount you wish to inject into it, preferably much more, since injection capacity will tend to decrease over time due to clogging. It may be necessary to place a pressure-tight cap on the well to keep the



return water from flowing out the top of the well. This cap is commonly required since a certain amount of pressure may be needed to force the return water back down the well in cases of limited injectivity.

Water discharged by percolation will generally soak into the ground within a distance of 50 to 100 ft. If suitable care is taken to ensure that the drain pipe runs downhill and the end of the pipe is protected by a bale of hay or spruce bows, the end of the pipe will not freeze as the pipe will empty out when the heat pump shuts off and the water valve closes. A screen should be installed on the end of large discharge pipes, to prevent animals from building nests inside during extended 'off' periods and causing a backflooding risk for open water drains.

When snow comes it will usually cover the entire process much like a small spring. It is recommended that the pipe be below the frost line when possible for maximum freeze protection.

When discharging into a river or stream, or above the surface of a pond, the same guidelines should be followed as described in the paragraph above for the percolation method.

When discharging the waste water below the surface of a pond or lake, the discharge pipe should be placed below the frost line to prevent the pipe from freezing. As opposed to the percolation method, water will remain in the end of the pipe. It is recommended that the surface of the pond be lower than the installation location of the heat pump. This reduces the back pressure generated by the weight of the water in the pond.

#### **Water Valve**

Water flow through the heat pump is turned on and off by a water valve, which is controlled by a 24VAC signal from the heat pump. It should be installed on the **OUT** pipe of the heat pump, so that the heat exchanger remains full of water at all times.

Most installations of small heat pumps like these use a fast acting solenoid valve. The valve will have 2 wires or two connections, to  $\mathbf{Y}$  and  $\mathbf{C}$  on the thermostat terminal strip in the heat pump's electrical box. A 'Rainbird' solenoid valve is available from Maritime Geothermal Ltd. as an accessory.

If water hammer associated with a fast acting valve is shown to be a problem, there are a couple of alternatives:

- Hailin or equivalent slow acting motorized ball valve, which is always powered with 24VAC from **R** and opened with a **Y** or **Y1** signal.
- **Taco** slow acting **motorized ball valve**, which is powered open and stores the energy required to close using a capacitor.

These take  $\sim$ 5 seconds to close, and avoid the water hammer which can occur with faster acting valves. If used, **Y** from the thermostat should be wired first to the valve, and then through the valve's end switch to **Y** on the heat pump's terminal strip.

## Low Pressure Control Selection

The purpose of the low pressure control is prevent heat exchanger freezing in the case of a flow problem.

Unlike other NORDIC model series, low pressure control selection for open loop for the R/RH 09-24 is done manually, with a wire jumper. For open loop (fresh water) operation, make sure a jumper is **not** connected between **LP1** and **LP2** on the heat pump's terminal strip. This will ensure the higher 75psi low pressure control is selected to prevent heat exchanger freezing in the case of a flow problem.

### Water Flow Control

A flow restricting ('Dole' or 'Hays') valve is highly recommended, installed downstream of the water valve. This is a passive (non-electrical) device which automatically varies the size of its rubber orifice in order to restrict flow to its stamped gpm value, regardless of water pressure. This is important in order to provide some backpressure to the water system, which could otherwise be too low for the comfort of people taking showers or otherwise using the domestic water system. It also prevents excessively low refrigerant discharge pressure when in cooling mode. Dole valves are available as an accessory.

Dole valves can emit a 'whistling' sound if the pressure drop through them is high. Therefore, they should be placed where the noise will not cause a nuisance, e.g. outside the basement wall or perhaps in a well insulated box. Hays flow restrictors do not have this drawback.

### **Submersible Pump Selection**

Of course, the submersible pump must be large enough to supply the flow required by the heat pump. This is usually not a problem, pumps often being oversized by default.

However, if a conventional fixed speed pump is too large, its fixed capacity will exceed that of the Dole valve at reasonable pressure switch settings (<80 psi). This will cause the submersible pump to cycle on and off continuously while the heat pump is running, causing excessive wear to the submersible pump. The installation of a large air bladder tank will cause the cycles to have a longer duration, but will not solve the problem.

To avoid this problem, the fixed speed pump should be sized according to its head vs. flow curve. The required head should be calculated using height between the pumping fluid level in the well and the elevation of the heat pump, pipe pressure drop at nominal flow rate, desired system water pressure, and any back pressure from return well. Then a pump can be selected that delivers the nominal flow for the chosen heat pump size at that head. In case this calculation is not exact, a variety of Dole valves can be carried by the installer, and a larger Dole valve installed if submersible pump cycling is observed.

An alternate approach would be to install a variable speed submersible pump, which varies its speed to maintain a constant water system pressure. Or use a mechanical 'cycle stop' valve, which is installed upstream of the air bladder / pressure tank and varies its orifice to put backpressure on the pump during periods of low flow in order to keep it from cycling off.

### **Plumbing the Heat Pump**

The port connections for the Outdoor Loop are 1/2" or 3/4" brass FPT fittings. They are marked as OUTDOOR IN and OUT.

Plumbing lines, both IN (supply) and OUT (discharge), must be of adequate size to handle the water flow necessary for the heat pump. A copper or plastic line should be run to the Outdoor IN pipe of the heat pump. Similarly, a line should be run from the Outdoor OUT pipe to the method of disposal. P/T plugs should be installed at each port. See diagram in the Ground Loop chapter for a description of P/T plugs. The water valve should be installed in the OUT (discharge) line. Refer to drawing **000907CDG** at the end of this section for the recommended setup. Placing the water valve in the discharge line ensures that the heat exchanger inside the heat pump remains full of water when the unit is not running. Unions or some other form of disconnect should be used so that the coaxial heat exchanger may be accessed should it required cleaning.

The heat pump has an electrical connector for the water valve just inside the case. After the water valve is installed, run the valve harness into the case through the hole provided. Remove the jumper plug from the Valve Connector and connect the harness in its place.

Optionally, a water flow meter can be installed in the discharge line so that the exact amount of water flowing can be determined at a glance. It should be placed between the Outdoor OUT (Supply OUT) pipe of the heat pump and the water valve.

With proper flow, there should be  $5-7^{\circ}F(3-4^{\circ}C)$  delta T between the IN and OUT water temperatures of the heat pump when operating in the heating mode.

All water line valves on both the supply and discharge lines should be either BALL or GATE valves. GLOBE valves have a higher pressure drop, meaning more pumping power to maintain the required flow to the heat pump.

### **Pipe Insulation**

All ground water piping to and from the Outdoor Loop ports on the heat pump should be insulated with 3/8" closed cell pipe insulation, to prevent condensation and dripping onto floors or walls.



# **Startup Procedure**

The Startup Record located in this manual is used in conjunction with this startup procedure to provide a detailed record of the installation. A completed copy should be left on site, a copy kept on file by the installer and a copy should be sent to Maritime Geothermal Ltd.

Check the boxes or fill in the data as each step is completed. For data boxes, circle the appropriate units.

## **Pre-Start Inspection**

#### Ductwork:

- 1. Verify that all ductwork has been completed and is firmly attached to the unit. Verify that any dampers or diverters are properly set for operation of the heat pump.
- 2. Verify that all registers are open and clear of any objects that would restrict the airflow.
- 3. Verify that a new air filter is installed and the cover is secured.
- 4. Verify the condensate drain is connected, properly vented and free of debris.
- 5. If a plenum heater has been installed, verify that it is securely fastened to the ductwork.

#### **Outdoor Loop (Ground Loop):**

- 1. Verify that all shutoff valves are fully open and there are no restrictions in the piping from the heat pump to the ground loop, and that full flow is available to the heat pump.
- 2. Verify that the entire system has been flooded and all the air has been purged as much as possible. Further purging may be required after the system has been operating for a while.
- 3. Verify that the loop contains the proper mix of antifreeze for the intended application. Record the type of antifreeze and the mixture value on the startup sheet; circle % Vol. or % Weight.
- 4. Record the static loop pressure on the startup sheet.

#### Outdoor Loop (Open Loop):

- 1. Verify there are no leaks in the connections to the unit. Verify the water valve is installed and properly oriented in the water out line.
- 2. Verify that there is flow control in water out line.

#### Electrical:

- 1. Ensure the power to the unit is off. Ensure the power to the plenum heater is off if equipped.
- 2. Verify all high voltage connections. Ensure that there are no stray wire strands, all connections are tight and the ground wire is connected tightly to the ground connector for the heat pump and plenum heater.
- 3. Record the fuse / circuit breaker size and wire gauge for the heat pump. Record the fuse / circuit breaker size, wire gauge and size of the plenum heater if installed.
- 4. Verify that the control connections to the thermostat and plenum heater (if installed) are properly connected and all control signals are off, so that the unit will not start up when the power is turned on.
- 5. Ensure all access panels except the lower one that provides access to the electrical box are in place.

## **Unit Startup**

The unit is now ready to be started. The steps below outline the procedure for starting the unit and verifying proper operation of the unit. It is recommended that safety glasses be worn during the following procedures.

#### Preparation:

- 1. Remove the caps from the service ports and connect a refrigeration manifold set to the unit.
- 2. Turn the power on to the heat pump and set the thermostat to OFF. Set up the thermostat as per the instructions provided with it so that it will function properly with the heat pump system (set for system type: heat pump). The O signal should be set to active in cooling mode.
- 3. Measure the following voltages on the compressor contactor and record them on the startup sheet: L1-L2, L2-L3, L1-L3.

#### Heating Mode:

- 1. Set the thermostat to heating mode and adjust the setpoint to activate heat pump. The fan should slowly ramp up to speed after the time delay of the thermostat expires (if applicable) and the compressor will start (allow 30-60 seconds for the water valve to open for ground water systems)
- 2. Check the refrigeration gauges. The suction and discharge pressures will depend on the loop temperatures, but they should be about 90-110PSIG and 260-360PSIG respectively for a typical start-up.
- 3. Monitoring the refrigeration gauges while the unit runs. Record the following after 10 minutes of runtime:
  - 1. Suction pressure
    - 2. Discharge pressure
    - 3. Duct Return temperature (poke a small hole in the flex collar and insert probe in airstream)
    - 4. Duct Supply temperature (poke a small hole in the flex collar and insert probe in airstream)
    - 5. Duct Delta T (should be between 22-32°F, 12-18°C)
    - 6. Outdoor Loop In (Supply In) temperature
    - 7. Outdoor Loop Out (Supply Out) temperature
    - 8. Outdoor Delta T (should be between 5-8°F, 3-4°C)
    - 9. Outdoor flow (if available)
    - 10. Compressor L1(C) current (black wire, place meter between electrical box and compressor)
- 4. Adjust the thermostat setpoint to the desired room temperature and let the unit run through a cycle. Record the setpoint, suction pressure, and discharge pressure when the unit shuts off.

#### **Cooling Mode:**

- 1. Set the thermostat to cooling mode and adjust the setpoint to activate heat pump.
- 2. Monitoring the refrigeration gauges while the unit runs. Record the following after 10 minutes of runtime:
  - 1. Suction pressure
  - 2. Discharge pressure
  - 3. Duct Return temperature
  - 4. Duct Supply Out temperature
  - 5. Duct Delta T
  - 6. Outdoor Loop In (Supply In) temperature
  - 7. Outdoor Loop Out (Supply Out) temperature
  - 8. Outdoor Delta T
- 3. Adjust the thermostat setpoint to the desired room temperature if possible, otherwise set it just low enough to allow the unit to run (i.e. 1°F / 0.5°C less than room temperature) and let the unit run through a cycle. Record the thermostat setpoint, suction pressure and discharge pressure when the unit shuts off.

#### Final Inspection:

- 1. Turn the power off to the unit (and plenum heater if installed) and remove all test equipment.
- 2. Install the electrical box cover and the access panel on the heat pump. Install the service port caps securely to prevent refrigerant loss. Install the electrical cover on the plenum heater if applicable.
- 3. Do a final check for leaks in the ground water / ground loop system and ensure the area is clean.
- 4. Turn the power on to the unit and the plenum heater if installed. Set the thermostat to the final settings.

#### Startup Record:

**1.** The installer shall sign and date the Startup Record and have the homeowner sign as well. The installer shall leave the Startup Record with the homeowner, retain a copy for filing and send a copy to Maritime Geothermal Ltd. for warranty registration.

	Startup R	ecord: R-Series	Size 09-24	R410a					
Installation Site		Startup Date	Installer						
City			Company						
Province			Model						
Country			Serial #						
Customer Name		Customer Phone #							
	Check boxes un	less asked to record	data. Circle	e data units					
		PRE-START INSPE	CTION						
Ductwork	Ductwork is completed, damp	ers/ diverters are adjust	ed						
	Registers are open and clear of objects								
	Air filter and end cap are installed								
	Condensate Drain is connected								
	Plenum heater is securely fas								
Ground Loop	All shut-off valve are open (ful	ll flow available)							
System	Loop is full and purged of air								
	Antifreeze type								
	Antifreeze concentration			% Vo	lume	% W	eight		
	Loop static pressure			psi	kPa			-	
Ground Water	Water Valve installed in return	n line							
System	Flow control installed in return	line							
Electrical	High voltage connections are				_				
	Circuit breaker (or fuse) size a	А		Ga.					
	Circuit breaker (or fuse) size,	A		Ga.		kW			
	Low voltage connections are o								
		STARTUP DA	ГА						
Preparation	Voltage across L1 and L2, L1	and L3, L2 and L3							VAC
Heating Mode	Suction Pressure / Discharge	Pressure					psi	kPa	
(10 minutes)	Duct Return, Duct Supply, and	d Delta T		In		Out		°F	°C
	Outdoor In (Supply In), Outdo	or Out (Supply Out), and	d Delta T	In		Out		°F	°C
	Outdoor Flow			lgpm	g	pm	L/s		
	Compressor L1 (black wire) c	urrent		A					
	Thermostat setpoint, suction a	and discharge pressures	at cycle end	°F	°C			psi	kPa
Cooling Mode	Suction Pressure / Discharge	Pressure					psig	kPa	
(10 minutes)	Duct Return, Indoor Out, and	Delta T		In		Out		°F	°C
	Outdoor In (Supply In), Outdo	or Out (Supply Out), and	d Delta T	In		Out		°F	°C
	Thermostat setpoint, suction a	and discharge pressures	at cycle end	°F	°C			psi	kPa

Date:		Installer Signature:		Customer Signature:	
At	otal of three copies	are required: one for	the homeowner, one for the	installer and on to be sen	t to Maritime Geothermal Ltd.

# **Routine Maintenance**

MAINTENANCE SCHEDULE								
It	tem	Interval	Procedure					
Air Filter		6 months	Inspect for dirt. Replace if necessary.					
Compressor Contactor		1 year	Inspect for pitted or burned points. Replace if necessary.					
Condensate Drain		1 year	Inspect for clogs. Clean if necessary.					
Control Board		When heat pump problem is suspected	Check status light for faults. Rectify problem if alarms found. See <b>Troubleshooting</b> chapter.					
Coaxial Heat Exchanger		When experiencing performance degrada- tion that is not ex- plained by a refrigera- tion circuit problem or low ground loop flow rate	Disconnect the outdoor loop and flush heat exchang- er with a calcium removing solution. Generally not required for closed loop or cold water open loop sys- tems; whenever system performance is reduced for warm water open loop systems (unusual).					

# **Troubleshooting Guide**

The following steps are for troubleshooting the heat pump. If the problem is with the domestic hot water or the plenum heater, proceed to those sections at the end of the troubleshooting guide. Repair procedures and reference refrigeration circuit diagrams can be found later in this manual.

- **STEP 1:** Verify that the display is present on the thermostat. If it is not, proceed to POWER SUPPLY TROUBLESHOOTING, otherwise proceed to STEP 2.
- **STEP 2:** Remove the door and electrical box cover and check to see if there is a fault code on the control board. If there is, record the fault code. Turn the power off, wait 10 seconds and turn the power back on. Set the thermostat to call for heating or cooling depending on the season.
- **STEP 3:** If a 24VAC signal does not appear across Y and C of the terminal strip within 6 minutes, proceed to the THERMOSTAT TROUBLESHOOTING section, otherwise proceed to STEP 4.
- **STEP 4:** If a fault code appears once a signal is present at Y and the compressor does not attempt to start, proceed to the FAULT CODE TROUBLESHOOTING section, otherwise proceed to STEP 5.
- **STEP 5:** If no fault codes appear and the compressor does not attempt to start, attempts to start but cannot, starts hard, or starts but does not sound normal, proceed to the COMPRESSOR TROUBLESHOOTING section, otherwise proceed to STEP 6.
- **STEP 6:** If the compressor starts and sounds normal, this means the compressor is OK and the problem lies elsewhere. Proceed to the OPERATION TROUBLESHOOTING section.
- **NOTE:** To speed up the troubleshooting process, the TEST jumper on the safety board can be placed to the YES position to change the anti-short cycle timer to 5 seconds. **Be sure to set it back to NO when servicing is complete**. Be aware that if left in the TEST position, functionality may automatically revert back to standard operation after a short period of time; remove jumper, install in standard position, run unit, and replace jumper in TEST position to re-activate.

POWER SUPPLY TROUBLESHOOTING								
Fault	Possible Cause	Verification	Recommended Action					
No power to the heat pump	Disconnect switch open (if installed) Verify disconnect switch is in the ON position.		Determine why the disconnect switch was opened, if all is OK close the switch.					
	Fuse blown / breaker trippedAt heat pump disconnect box, voltmeter shows 230VAC on the line side but not on the load side.		Reset breaker or replace fuse with proper size and type. (Time-delay type "D")					
No display on thermostat.	Transformer impedance protection tripped or faulty transformer	230VAC is present across L1 and L3 of the compressor contactor but 24VAC is not present across R and C of the terminal strip.	Replace transformer.					
	Faulty wiring between heat pump and thermostat	24VAC is not present across C and $R(R_H)$ of the thermostat.	Correct the wiring.					
	Faulty Thermostat	24VAC is present across C and R $(R_H)$ of the thermostat but thermostat has no display.	Replace thermostat.					

THERMOSTAT TROUBLESHOOTING					
Fault	Possible Cause	Verification	Recommended Action		
No Y signal to heat pump (after 6 minutes)	Incorrect thermostat setup	Thermostat does not indicate a call for heat. No 24VAC signal present across Y & C of the thermostat	Correct the setup.		
	Faulty thermostat to heat pump wiring	24VAC signal present across Y & C of the thermostat but not present across Y & C of the terminal strip.	Correct or replace wiring		
	Faulty thermostat	No 24VAC between Y & C of the thermostat when a call is indicated.	Replace thermostat.		

FAULT CODE	FAULT CODE TROUBLESHOOTING				
Fault	Possible Cause	Verification	Recommended Action		
Fault Code 1 (High Pressure Control)	High operating refrigerant pressure	Using a refrigeration gauge set, veri- fy that high pressure approaches or exceeds 565psi with compressor on.	See "High Discharge Pressure" in Heating Mode / Cooling Mode Troubleshooting section.		
	Faulty High Pressure Con- trol, failed open ( <b>very unlikely</b> ) * For this test there must be a signal present on Y, but com- pressor should not be run- ning (disconnect compressor wires)	Verify that there is 24VAC across HPS (right terminal) on the control board and C of the terminal strip, as well as HPS (left terminal) and C.	Replace high pressure control if voltage is present on one terminal but not the other.		
	Faulty control board ( <b>very unlikely</b> )	24VAC is present across HPS (right terminal) and C of the terminal strip, as well as HPS (left terminal) and C, but is not present across CC on the control board and C after 10 minutes.	Replace control board.		
Fault Code 2 (Low Pressure Control)	Low operating refrigerant pressure	Using a refrigeration gauge set, veri- fy that low pressure approaches or dips below 55psi (ground loop) or 75 psi (open loop) with compressor on.	See "Low Discharge Pressure" in Heating Mode / Cooling Mode Troubleshooting section.		
	Faulty low pressure con- trol, failed open ( <b>very unlikely</b> ) * For this test there must be a signal present on Y, but com- pressor should not be run- ning (disconnect compressor wires)	Verify if there is 24VAC across LPS on the control board and C of the terminal strip, as well as HPS (left terminal) and C.	Replace high pressure control if voltage is present on one terminal but not the other.		
	Faulty control board ( <b>very unlikely</b> )	24VAC is present across LPS and C of the terminal strip, as well as HPS (left terminal) and C, but is not pre- sent across CC on the control board and C after 10 minutes.	Replace control board.		
	Little or no refrigerant in unit	With compressor off, use a refrigera- tion gauge set to check refrigeration pressure of the unit for a very low value (less than 100 psi).	Locate the leak and repair it. Spray 9, a sniffer, and dye are common methods of locating a leak.		
Fault Code 4 (Condensate overflow)	Condensate overflow	Drip tray under air coil is full of water up to the terminals of the conden- sate sensor.	Locate blockage or other cause of drain problem and rectify.		
Fault Code 5 (Brownout)	Low voltage from the elec- trical grid	Verify that the electrical supply has dropped below ~165VAC, causing transformer voltage to drop below 18VAC.	Contact electrical utility or wait for regular service to be restored.		

COMPRESSOR TROUBLESHOOTING			
Fault	Possible Cause	Verification	Recommended Action
Compressor will not start	Faulty control board	Measuring from C on the terminal strip, verify there is voltage at Y, HP1, HP2, LP1, LP2, and both flow pins but no voltage present at CC.	Replace control board.
	Faulty run capacitor (Single phase only)	Check value with capacitance meter. Should match label on capacitor. Compressor will hum while trying to start and then trip its overload.	Replace if faulty.
	Loose or faulty wiring	Check all compressor wiring, includ- ing inside compressor electrical box.	Fix any loose connections. Re- place any damaged wires.
	Faulty compressor contactor	Voltage on line side with contactor held closed, but no voltage on one or both terminals on the load side. Points pitted or burned. Or, 24VAC across coil but contactor will not engage.	Replace contactor.
	Thermal overload on compressor tripped	Ohmmeter shows reading when placed across R and S terminals and infinity between C & R or C & S. A valid resistance reading is present again after the compressor has cooled down.	Proceed to Operation Trouble- shooting (particularly <i>high suction</i> <i>pressure</i> and <i>high discharge pres-</i> <i>sure</i> ) to determine the cause of the thermal overload trip.
	Burned out motor (open winding)	Remove wires from compressor. Ohmmeter shows infinite resistance between any two terminals Note: Be sure compressor overload has had a chance to reset. If compressor is hot this may take several hours.	Replace the compressor.
	Burned out motor (shorted windings)	Remove wires from compressor. Resistance between any two termi- nals is below the specified value.	Replace the compressor.
	Motor shorted to ground	Remove wires from compressor. Check for infinite resistance be- tween each terminal and ground.	If any terminal to ground is not infinite replace the compressor.
	Seized compressor due to locked or damaged mechanism	Compressor attempts to start but trips its internal overload after a few seconds. (Run capacitor already verified)	Attempt to "rock" compressor free. If normal operation cannot be established, replace compressor.
Compressor starts hard	Start capacitor faulty (Single phase only)	Check with capacitance meter. Check for black residue around blowout hole on top of capacitor.	Replace if faulty. Remove black residue in electrical box if any.
	Potential Relay faulty (Single phase only)	Replace with new one and verify compressor starts properly.	Replace if faulty.
	Compressor is "tight" due to damaged mechanism	Compressor attempts to start but trips its internal overload after a few seconds. Run capacitor has been verified already.	Attempt to "rock" compressor free. If normal operation cannot be es- tablished, replace compressor.

OPERATION TROUBLESHOOTING - HEATING MODE				
Fault	Possible Cause	Verification	Recommended Action	
High Discharge Pressure	Low airflow	See Fan Troubleshooting section	Correct the problem.	
	TXV adjusted too far closed	Verify superheat. It should be be- tween 8-12°F (3-6°C). Superheat will be high if TXV is closed too far.	Adjust TXV to obtain 8-12°F (3-6°C) superheat.	
	TXV stuck almost closed or partially blocked by for- eign object	Adjusting the TXV does not affect the superheat or the suction pressure.	Adjust the TXV all the way in and out a few times to loosen it. Re- place TXV if this does not work.	
	Filter-dryer plugged	Feel each end of the filter- dryer; they should be the same temperature. If there is a temperature difference then it is plugged. Also causes low suc- tion pressure.	Replace filter-dryer.	
	Unit is overcharged (Only possible if unit has been field serviced and incorrectly charged)	High subcooling, low delta T across air coil.	Remove 1/2lb of refrigerant at a time and verify that the discharge pressure reduces. Or remove charge and weigh back in the amount listed on nameplate.	
Low Suction Pressure	Low or no outdoor liquid flow	Delta T across the Outdoor Loop ports should be 5-7°F (3-4°C), or compare pressure drop to the tables for the unit.	Determine the cause of the flow restriction and correct it. Verify pumps are working and sized correctly for ground loop systems. Verify well pump and water valve is working for ground water sys- tems.	
	Entering liquid tempera- ture too cold	Measure the entering liquid tempera- ture to see if it is less than ~25F.	Increase the size of the ground loop.	
	Dirty or fouled coaxial heat exchanger (more likely for open loop, un- likely for ground loop)	Disconnect the water lines and check the inside of the pipes for scale de- posits.	Backflush the coaxial exchanger with a calcium-removing cleaning solution.	
	Return air too cold	Measure return air temperature. Should be above 60°F (15°C).	Restrict air flow temporarily until room comes up to temperature.	
	TXV stuck almost closed or partially blocked by for- eign object	Adjusting the TXV does not affect the superheat or the suction pressure. TXV may be frosting up.	Adjust the TXV all the way in and out a few times to loosen it. Re- place TXV if this does not work.	
	Low refrigerant charge	Entering liquid temperature, flow and entering air temperature are good but suction is low. Check static refrigera- tion pressure of the unit for a very low value. Weigh refrigerant out and compare to charge listed on name- plate.	Locate the leak and repair it. Spray 9, a sniffer, and dye are common methods of locating a leak.	
High Suction Pressure (may appear to not be pumping)	Faulty compressor, not pumping	Pressures change only slightly from static values when compressor is started.	Replace compressor.	

OPERATION TR	OPERATION TROUBLESHOOTING - HEATING MODE			
Fault	Possible Cause	Verification	Recommended Action	
High Suction Pressure (may appear to not be pumping)	Leaking reversing valve (can cause compressor to overheat and trip internal overload)	Reversing valve is the same temper- ature on both ends of body, com- mon suction line is warm, compres- sor is running hot, low compressor discharge pressure.	Tap reversing valve, and switch it back and forth between heating and cooling positions. If this does not work for a long term fix, re- place reversing valve.	
	TXV adjusted too far open tween 8-12°F (3-6°C). Superheat will be low if TXV is open too far.A		Adjust TXV to obtain 8-12°F (3-6°C) superheat.	
	TXV stuck open	Adjusting the TXV does not affect the superheat or the suction pres- sure. Low super heat and discharge pressure.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.	
Compressor frosting up	See Low Suction Pressure in this section			
TXV frosting up	TXV stuck almost closed or partially blocked by for- eign object	Adjusting the TXV does not affect the superheat or the suction pressure.	Attempt to adjust the TXV all the way out and all the way in a few times to loosen it. Replace TXV if this does not work.	
Random high pressure trip (does not occur while on site)	urFaulty compressor contactorPoints pitted or burned. ContactorurFaulty compressor contactorsometimes sticks causing the compressor to run without the fan, the ping the high pressure control.		Replace contactor.	
	Intermittent fan	See Fan Troubleshooting section.	Correct the problem.	

OPERATION T	OPERATION TROUBLESHOOTING - COOLING MODE				
Fault	Possible Cause	Verification	Recommended Action		
Heating instead of cooling	Thermostat not set up properly	Verify that there is 24VAC across O and C of the terminal strip when calling for cooling.	Correct thermostat setup. Change to a different thermostat.		
	Faulty reversing valve so- lenoid coil	Verify solenoid by removing it from the shaft while the unit is running. There should be a loud "whoosh" sound when it is removed.	Replace solenoid if faulty.		
	Faulty reversing valve	A click can be heard when the coil is energized but the unit continues to heat instead of cool.	Replace reversing valve.		
High Discharge pressure	Low or no outdoor liquid flow	Delta T across the outdoor loop ports should be between 8-12°F (4-7°C), or compare pressure drop to the tables for the unit.	Determine the cause of the flow restriction and correct it. Verify pumps are working for ground loop systems. Verify well pump and water valve is working for ground water systems.		
	Entering liquid tempera- ture too warm	Most likely caused by undersized ground loop.	Verify the ground loop sizing. In- crease the size of the ground loop if undersized.		
	Dirty or fouled coaxial heat exchanger (more likely for open loop, un- likely for ground loop)	Disconnect the water lines and check the inside of the pipes for scale deposits.	Backflush the coaxial exchanger with a calcium-removing cleaning solution.		

OPERATION T	ROUBLESHOOTING -	G - COOLING MODE				
Fault	Possible Cause	Verification	Recommended Action			
High Discharge pressure	Unit is overcharged (Only possible if unit has been field serviced and incorrectly charged)	High subcooling, low delta T across water coil.	Remove 1/2lb of refrigerant at a time and verify that the discharge pressure reduces. Or remove charge and weigh back in the amount listed on nameplate.			
High Suction Pressure (may appear to not be pumping)	TXV adjusted too far open	Verify superheat. It should be be- tween 8-12°F (3-6°C). Superheat will be low if TXV is open too far.	Adjust TXV to obtain 8-12°F (3-6°C) superheat.			
	TXV stuck open	Adjusting the TXV does not affect the superheat or the suction pres- sure. Low super heat and dis- charge pressure.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.			
	Leaking reversing valve (can cause compressor to overheat and trip internal overload)	Reversing valve is the same tem- perature on both ends of body, common suction line is warm, com- pressor is running hot, low com- pressor discharge pressure.	Tap reversing valve, and switch it back and forth between heating and cooling positions. If this does not work for a long term fix, replace reversing valve.			
	Faulty compressor, not pumping	Pressures change only slightly from static values when compressor is started.	Replace compressor.			
Low Suction Pressure	Low airflow	See Fan Troubleshooting section. <b>Note:</b> low airflow will cause the air coil to ice up once the suction drops below <b>90PSIG</b> .	Correct the problem.			
	TXV stuck almost closed or partially blocked by for- eign object	Adjusting the TXV does not affect the superheat or the suction pres- sure. TXV may be frosting up.	Adjust the TXV all the way in and out a few times to loosen it. Re- place TXV if this does not work.			
	Low or no refrigerant charge	Entering air temperature and air- flow are good but suction is low. Check static refrigeration pressure of the unit for a very low value. Weigh refrigerant out and compare to charge listed on nameplate.	Locate the leak and repair it. Spray 9, a sniffer, and dye are common methods of locating a leak.			
Compressor frosting up	See Low Suction Pressure in this section					
TXV frosting up	TXV stuck almost closed or partially blocked by for- eign object.	Adjusting the TXV does not affect the superheat or the suction pres- sure.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.			
Random Low Pressure trip (does not occur while there)	Faulty compressor contactor	Points pitted or burned. Contactor sometimes sticks causing the com- pressor to run without the fan, trip- ping the low pressure control.	Replace contactor.			
	Intermittent fan	See Fan Troubleshooting section.	Correct the problem.			

FAN/BLOWER	AN/BLOWER TROUBLESHOOTING				
Fault	Possible Cause	Verification	Recommended Action		
Low Airflow	Dirty air filter	Inspect.	Replace.		
	Dirty air coil	Inspect.	Clean.		
	Poor Ductwork	Measure delta T between supply and return ducts at the unit, it in heating mode, it should not be above 30°F(17°C).	The ECM can provide only a cer- tain amount of torque, according to the speed SP1/SP2/SP3/SP4 selected. The ductwork is poorly designed or greatly undersized if the fan motor cannot provide the required airflow.		
	Airflow selected on 4- speed terminal strip (SP1/SP2/SP3/SP4) is too low	Check selection.	Select a higher setting.		
Fan operating on wrong speed, or does not respond to speed selec- tion change	Fan Control Signal Har- ness is loose	Verify that the connector is properly inserted into the fan motor. Gently tug on each wire to verify it is properly inserted into the connector.	Repair any loose connections.		
	Faulty Control Signal Har- ness or faulty motor head Ensure signal is present on terminal strip	Measure 24VAC between White/ Black (pin C) and the following at the fan control signal harness (insert probes in connector where wire is inserted, do not unplug the connect- or): Recirculation = red (pin 1) SP1 = orange (pin 2) SP2 = blue (pin 3) SP3 = brown (pin 4) SP4 = grey (pin 5)	If proper signal isn't present, re- place Fan Control Signal Har- ness. If proper signal is present, replace fan motor head.		
Fan not operat- ing or operating intermittently	Fan Control Signal Har- ness and/or Fan Power Harness is loose	Verify that the connector is properly inserted into the fan motor. Gently tug on each wire to verify it is properly inserted into the connector.	Repair any loose connections.		
	Faulty Control Signal Har- ness or faulty motor head Ensure signal is present on terminal strip	Measure 24VAC between White/ Black (pin C) and the following at the fan control signal harness (insert probes in connector where wire is inserted, do not unplug the connect- or): Recirculation = red (pin 1) SP1 = orange (pin 2) SP2 = blue (pin 3) SP3 = brown (pin 4) SP4 = grey (pin 5)	If proper signal isn't present, re- place Fan Control Signal Har- ness. If proper signal is present, replace fan motor head.		
	Faulty Fan Power Har- ness or faulty motor	Insert the tips of the voltmeter probes into the back of the connect- or at the fan to measure the voltage across the red and black wires. Value should be 230VAC.	Replace Power Harness if 230VAC is not present, replace motor if 230VAC is present		

# **Repair Procedures**

#### Pumpdown Procedure

- Connect the refrigerant recovery unit to the heat pump's internal service ports via a refrigeration charging manifold and to a recovery tank as per the instructions in the recovery unit manual. Plan to dispose of refrigerant if there was a compressor burnout.
- 2. All refrigerant to water heat exchangers (brazed plates) **must either have full flow or be completely drained** of fluid before recovery begins. Failure to do so can freeze and rupture the heat exchanger, voiding its warranty.
- 3. Ensure all hose connections are properly purged of air. Start the refrigerant recovery as per the instructions in the recovery unit manual.
- 4. Allow the recovery unit suction pressure to reach a vacuum. Once achieved, close the charging manifold valves. Shut down, purge and disconnect the recovery unit as per the instructions in its manual. Ensure the recovery tank valve is closed before disconnecting the hose to it.
- Connect a nitrogen tank to the charging manifold and add nitrogen to the heat pump until a positive gauge pressure of 5-10 psig is reached. This prevents air from being sucked into the unit by the vacuum when the hoses are disconnected.

The heat pump is now ready for repairs.

#### General Repair Procedure

- 1. Perform repairs to system.
  - Always ensure nitrogen is flowing through the system at the lowest flow rate that can be felt at the discharge during any brazing procedures to prevent soot buildup inside the pipes.
  - It is recommended to replace the liquid line filter-dryer any time the refrigeration system has been exposed to the atmosphere.
  - Place a wet rag around any valves being installed, as almost all valve types have non-metallic seats or seals that will be damaged by excessive heat, and aim the torch flame away from the valve body. Solder only one joint at a time and cool joints down in between.
- 2. Pressure test the system with nitrogen. It is recommended to check for leaks using leak detection spray, Spray Nine, or soapy water. Check at 10, 25, 50 and 100 psig. Allow the system to sit at 100 psig for at least an hour, then re-check.

### Vacuuming & Charging Procedure

After completion of repairs and nitrogen pressure testing, the refrigeration circuit is ready for vacuuming.

- 1. Release the nitrogen pressure and connect the vacuum pump to the charging manifold. Start the vacuum pump and open the charging manifold valves. Vacuum until the vacuum gauge remains at less than 500 microns for at least 1 minute with the vacuum pump valve closed.
- 2. Close the charging manifold valves then shut off and disconnect the vacuum pump. Place a refrigerant tank with the proper refrigerant on a scale and connect it to the charging manifold. Purge the hose to the tank.
- 3. Weigh in the appropriate amount **and type** of refrigerant through the low pressure (suction) service port. Refer to the nameplate label on the unit for the proper refrigerant type and charge amount.
- 4. If the unit will not accept the entire charge, the remainder can be added through the low pressure service port after the unit has been restarted.

#### **Compressor Replacement Procedure**

- 1. Pump down the unit as per the Pumpdown Procedure above. If there was a compressor burn out (motor failure), the refrigerant cannot be reused and must be disposed of according to local codes.
- 2. Disconnect piping.
- Replace the compressor. Replace the liquid line filter-dryer. Always ensure nitrogen is flowing through the system at the lowest flow rate that can be felt at the discharge during any brazing procedures to prevent soot buildup inside the pipes.
- 4. Vacuum the unit as per above procedure.
- 5. If there was a compressor burnout:
  - *a)* Charge the unit with **new** refrigerant and operate it for continuously for 2 hours. Pump down the unit and replace the filter-dryer. Vacuum the unit as per above procedure.
  - *b)* Charge the unit (refrigerant can be re-used) and operate it for 2-3 days. Perform an acid test. If it fails, pump down the unit and replace the filter-dryer.
  - *c)* Charge the unit (refrigerant can be re-used) and operate it for 2 weeks. Perform and acid test. If it fails, pump down the unit and replace the filter-dryer.
- 5. Charge the unit a final time. Unit should now be clean and repeated future burn-outs can be avoided.

#### Blower Motor Replacement Procedure

See **Air Outlet Orientation** in the **Installation Basics** chapter for an illustration of the blower being removed through the adjacent service access panel. In this way, the nut securing the blower wheel to the motor shaft can be loosened to change the motor, without having access to the back of the unit.

# **Model Specific Information**

Table 14 - Refrigerant Charge					
MODEL	lb	kg	Refrigerant	Oil Type	
R-09	1.9	0.86	R410a	POE	
R-12	2.0	0.91	R410a	POE	
R-18	2.3	1.0	R410a	POE	
R-24	2.8	1.3	R410a	POE	
RH-09	1.9	0.86	R410a	POE	
RH-12	2.0	0.91	R410a	POE	
RH-18	2.3	1.0	R410a	POE	
RH-24	2.8	1.3	R410a	POE	
Oil capacity is marked on the compressor label					

Oil capacity is marked on the compressor label.
Refrigerant charge is subject to revision; actual charge is indicated on the unit nameplate.

Table 15	Table 15 - Shipping Information					
MODEL	SHIPPING WEIGHT	HANGING WEIGHT	DIMENSIONS inches (cn			
	lb (kg)	lb (kg)	L	W	Н	
R-09	161 (73)		25 (64)	28 (71)	48 (122)	
R-12	166 (75)		25 (64)	28 (71)	48 (122)	
R-18	187 (85)		25 (64)	28 (71)	48 (122)	
R-24	250 (114)		25 (64)	28 (71)	48 (122)	
RH-09	161 (73)	125 (57)	41 (104)	21 (53)	16 (41)	
RH-12	172 (78)	136 (62)	41 (104)	21 (53)	16 (41)	
RH-18	190 (86)	148 (67)	48 (122)	21 (53)	18 (46)	
RH-24	RH-24         250 (114)         208 (95)         48 (122)         21 (53)         18 (46)					
See Dimer	nsions later in this	manual for RH-s	eries hange	r weight dis	tribution.	

Table 16 -	Table 16 - Operating Temperature Limits						
Loop	Mode	Parameter	°F	°C	Note		
	Heating (water/open loop)	Minimum ELT	41	5			
OUTDOOR	Heating (antifreeze/ground loop)	Minimum ELT	23	-5	Adequate antifreeze concentration required.		
(ground	Heating	Maximum ELT	80	27	Reduce flow above this temperature.		
loop)	Cooling	Minimum ELT	41	5	Flow reduction may be required.		
	Cooling	Maximum ELT	110	43			
	Heating	Minimum EAT	60	16	Reduce air flow if necessary during heating startup.		
INDOOR	Heating	Maximum EAT	100	38			
(air duct)	Cooling	Minimum EAT	50	10			
	Cooling	Maximum EAT	100	38	Reduce air flow if necessary during cooling startup.		
* Values in t	his table are for rated liquid and air	flow values.					

## **Pressure Drop Data**

Table 17: Loop Pressure Drop Data     Water 104°F     Water 50°F     15% Methan	15% Methanol 32°F		35% prop. glycol 32°F	
gpm <i>L/s</i> psi <i>kPa</i> psi <i>kPa</i> psi	kPa	psi	kPa	
1.5         0.09         1.4         9.7         1.5         10         1.7	12	2.3	16	
2 0.13 <b>2.4 17</b> 2.6 18 2.9	20	3.6	25	
R-09 2.5 0.16 3.6 25 3.9 27 4.1	28	5.5	38	
RH-09         3         0.19         5.1         35         5.3         37         5.9	41	7.4	51	
3.5         0.22         6.7         46         6.9         48         7.7	53	9.7	67	
4         0.25         8.4         58         8.6         59         9.5	66	12	83	
	1.			
1.5         0.09         1.4         9.7         1.5         10         1.7	12	2.3	16	
2 0.13 2.4 17 2.6 18 2.9	20	3.6	25	
<b>R-12</b> 2.5 0.16 3.6 25 3.9 27 4.1	28	5.5	38	
N1-12         3         0.19         5.1         35         5.3         37         5.9	41	7.4	51	
3.5 0.22 6.7 46 6.9 48 7.7	53	9.7	67	
4 0.25 <b>8.4</b> 58 8.6 59 9.5	66	12	83	
2.5 0.16 0.8 5.5 0.8 5.5 0.9	6.2	1.4	9.7	
3 0.19 1.0 6.9 1.1 7.6 1.2	8.3	1.9	13	
3.5 0.22 1.4 9.7 1.5 10 1.7	12	2.3	16	
<b>R-18</b> 4 0.25 1.7 12 1.8 12 2.0	14	2.6	18	
RH-18 4.5 0.28 2.1 15 2.3 16 2.6	18	3.2	22	
5 0.32 2.5 17 2.7 19 3.0	21	3.8	26	
5.5 0.35 3.1 21 3.4 23 3.8	26	4.8	33	
6         0.38         3.6         25         3.9         27         4.3	30	5.5	38	
4         0.25         0.9         6.2         1.0         6.9         1.1	7.6	1.7	12	
5         0.32         1.4         9.7         1.5         10         1.7	12	2.3	16	
6         0.38         1.9         13         2.1         15         2.3	16	2.9	20	
R-24         7         0.44         2.5         17         2.7         19         3.0	21	3.8	26	
8         0.50         3.1         21         3.4         23         3.8	26	4.8	33	
9         0.57         4.0         28         4.3         30         4.8	33	6.0	41	
10         0.63         4.9         34         5.1         35         5.7	39	7.1	49	
	83	10	13	
4         0.23         1.0         0.9         1.1         7.0         1.2           5         0.32         1.4         9.7         1.5         10         1.7	12	23	16	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	16	2.0	20	
BH-24         7         0.44         25         17         27         19         30	21	3.8	26	
8         0.50         32         22         35         24         30	21	0.0	20	
0 0.00 0.2 22 0.0 24 0.3	27	49	34	
9 0.57 41 28 43 30 48	<b>27</b> 33	<b>4.9</b>	<b>34</b> 41	

## **Standard Capacity Ratings**

Standards C13256-1 / ISO13256-1 / ARI 13256-1

Table	18 - Stano	dard Cap	acity I	Ratings	- Grou	nd Loop I	Heating*		60Hz
EAT 68°	F (20°C)	* 15% Meth	nanol by	Weight G	round Loo	op Fluid		ELT	32°F (0°C)
Model	Nominal Size	Liquid F	low	Airf	low	Input Energy	Сара	city	COP <sub>H</sub>
Size	kW	W/W							
09	0.75	2.5	0.16	325	153	645	8,700	2.5	3.94
12	1	3.0	0.19	400	189	920	11,800	3.5	3.75
18	1.5	4.5	0.28	650	307	1,175	14,700	4.3	3.66
24	2	8.0	0.50	800	380	1,629	19,900	5.8	3.58

Table	19 - Stand	dard Cap	acity F	Ratings	- Grou	nd Water	Heating		60Hz						
EAT 68°	'F (20°C)							ELT 5	0°F (10°C)						
Model	Model Size         Nominal Liquid Flow         Liquid Flow         Airflow         Input Energy         Capacity         COP <sub>H</sub> Size         tang         app         L/g         off         L/g         Watta         Ptu/br         MAN														
Size	Size tons gpm L/s cfm L/s Watts Btu/hr kW W/W														
09	0.75	2.5	0.16	325	153	695	10,000	2.9	4.20						
12	1	3.0	0.19	400	189	945	13,500	4.0	4.18						
18	1.5	4.5	0.28	650	307	1,295	18,400	5.4	4.16						
24	2	8.0	0.50	800	380	1,758	25,500	7.5	4.25						

Table 2	0 - Stand	dard Cap	acity F	Ratings	- Grou	nd Loop	Cooling*			60Hz					
EAT 80.6	°F (27°C) ,	RH=46%	* 15%	Methanol b	y Weight	Ground Loop	o Fluid		ELT 77	7°F (25°C)					
Model	Model Size         Size         Liquid Flow         Airflow         Input Energy         Capacity         EER         COPc														
Size	Size tons gpm L/s cfm L/s Watts Btu/hr kW Btu/hr/W W/W														
09	0.75	2.5	0.16	325	153	600	10,400	3.0	17.3	5.08					
12	1	3.0	0.19	400	189	740	12,800	3.8	17.3	5.07					
18	1.5	4.5	0.28	650	307	1,060	18,200	5.3	17.2	5.05					
24	2	8.0	0.50	800	380	1,474	25,200	7.4	17.1	5.01					

Table 2	1 - Stand	lard Capa	acity R	atings	- Grou	nd Water	Cooling			60Hz					
EAT 80.6	°F (27°C) ,	RH=46%							ELT 5	9°F (15°C)					
Model	Model         Size         Liquid Flow         Airflow         Input Energy         Capacity         EER         COPc														
	tons gpm L/s cfm L/s Watts Btu/hr kW Btu/hr/W W/W														
09	0.75	2.5	0.16	325	153	520	11,900	3.5	22.8	6.69					
12	1	3.0	0.19	400	189	600	13,600	3.9	22.7	6.64					
18	1.5	4.5	0.28	650	307	935	19,900	5.8	21.4	6.26					
24	2	8.0	0.50	800	380	1,252	27,300	8.0	21.8	6.39					

1	-	-			/	,										
	(	OUTDO	OR LOO	<b>) OP</b> (15	% Meth	anol)	ELE	CTRIC	AL			INDO	OR LO	OP (Air)		
	ELT (°F)	Evap. Temp.	Flow (gpm)	LLT (°F)	Delta T (°F)	Heat Abs. (Btu/hr)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°F)	Cond. Temp.	Airflow (cfm)	LAT (°F)	Delta T (°F)	Heating (Btu/hr)	СОРн
DNI	29	20	2.5	24	5.3	6,334	2.8	82	633		102	325	94	26.1	8,494	3.93
	35	25	2.5	29	5.6	6,604	2.8	82	654		104	325	95	27.2	8,836	3.96
F	41	30	2.5	35	5.8	6,865	2.8	82	675		106	325	96	28.2	9,169	3.98
	47	35	2.5	41	6.1	7,228	2.8	82	688	68	108	325	98	29.5	9,577	4.08
Ĩ	50	39	2.5	44	6.1	7,608	2.8	82	696	00	110	325	99	30.7	9,982	4.20
	57	45	2.5	50	6.8	8,445	2.9	82	706		112	325	101	33.4	10,854	4.51
	63	50	2.5	56	7.4	9,208	2.9	82	715		114	325	104	35.8	11,649	4.77
	69	55	2.5	61	8.0	9,997	3.0	82	726		116	325	106	38.4	12,474	5.04

#### R/RH-09-HAC-P-1L R410a, 60 Hz, GKS086

	C	OUTDO	OR LO	<b>OP</b> (15	% Metha	anol)	ELE	CTRIC	AL			IND	OOR L	.00P (A	ir @ 46	% RH)		
	ELT (°F)	Cond. Temp.	Flow (gpm)	LLT (°F)	Delta T (°F)	Heat Rej. (Btu/hr)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°F)	Evap. Temp.	Airflow (cfm)	LAT (°F)	Delta T (°F)	Latent (Btu/hr)	Sensible (Btu/hr)	Cooling (Btu/hr)	EER
48	51	70	2.5	63	11.7	14,665	1.7	93	494		44	325	53	27.2	4,154	8,826	12,980	26.3
SNI	56	75	2.5	67	11.3	14,121	1.9	93	510		44	325	55	25.9	3,962	8,420	12,382	24.3
	61	80	2.5	72	10.7	13,394	2.0	93	529		44	325	56	24.2	3,709	7,881	11,590	21.9
0	66	85	2.5	76	10.4	13,050	2.1	93	548	80.6	45	325	57	23.4	3,577	7,601	11,178	20.4
8	72	90	2.5	83	10.8	12,787	2.2	93	571	00.0	45	325	58	22.7	3,469	7,371	10,840	19.0
	77	95	2.5	88	10.5	12,417	2.4	93	598		45	325	59	21.7	3,320	7,055	10,375	17.3
	82	100	2.5	92	10.2	12,119	2.5	93	628		45	325	60	20.9	3,192	6,783	9,975	15.9
	87	105	2.5	97	10.0	11,877	2.6	93	660		45	325	61	20.1	3,080	6,544	9,624	14.6

METRIC	2																	
	(	OUTDO	OR LO	<b>OP</b> (15	5% Meth	anol)	ELE	CTRIC	AL			INDO	OR LO	OP (Air)			1	
	ELT (°C)	Evap. Temp.	Flow (L/s)	LLT (°C)	Delta T (°C)	Heat Abs. (W)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°C)	Cond. Temp.	Airflow (L/s)	LAT (°C)	Delta T (°C)	Heating (W)	СОРн		
m	-1.7	-6.7	0.16	-4.6	3.0	1,856	2.8	82	633		38.9	153	34.5	14.5	2,489	3.93		
ž	1.7	-3.9	0.16	-1.4	3.1	1,935	2.8	82	654		40.0	153	35.1	15.1	2,589	3.96		
E	5.0	-1.1	0.16	1.8	3.2	2,012	2.8	82	675		41.1	153	35.7	15.7	2,687	3.98		
	8.3	1.7	0.16	5.0	3.4	2,118	2.8	82	688	20	42.2	153	36.4	16.4	2,806	4.08		
I I	10.0	3.9	0.16	6.6	3.4	2,229	2.8	82	696	20	43.3	153	37.1	17.1	2,925	4.20		
	13.9	7.2	0.16	10.1	3.8	2,474	2.9	82	706		44.4	153	38.6	18.6	3,180	4.51		
	17.2	10.0	0.16	13.1	4.1	2,698	2.9	82	715		45.6	153	39.9	19.9	3,413	4.77		
	20.6	12.8	0.16	16.1	4.4	2,929	3.0	82	726		46.7	153	41.3	21.3	3,655	5.04		
			<u></u>	<u></u>	0/ NA //	0				1								_
		JUIDO	OR LO	<b>OP</b> (15	% Meth	anoi)	ELE	CIRIC	;AL			INC	DOOR L	.00P (A	Air @ 46	% RH)		
	ELT (°C)	Cond. Temp.	Flow (L/s)	LLT (°C)	Delta T (°C)	Heat Rej. (W)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°C)	Evap. Temp.	Airflow (L/s)	LAT (°C)	Delta T (°C)	Latent (W)	Sensible (W)	Cooling (W)	

494

510

529

548

571

598

628

660

6.7

6.8

6.9

7.0

7.1

7.2

7.3

7.4

27

153

153

153

153

153

153

153

153

11.9

12.6

13.5

14.0

14.4

14.9

15.4

15.8

15.1

14.4

13.5

13.0

12.6

12.1

11.6

11.2

1,217

1,161

1,087

1,048

1,016

973

935

902

2,586

2,467

2,309

2,227

2,160

2,067

1,987

1,917

93

93

93

93

93

93

93

93

1.7

1.9

2.0

2.1

2.2

2.4

2.5

2.6

\*\* Fan power at 24.9Pa (0.10inH<sub>2</sub>O) external static.

21.1

23.9

26.7

29.4

32.2

35.0

37.8

40.6

10.6

13.3

16.1

18.9

22.2

25.0

27.8

30.6

DNIJOOD

0.16

0.16

0.16

0.16

0.16

0.16

0.16

0.16

17.1

19.6

22.1

24.7

28.2

30.8

33.4

36.1

6.5

6.3

6.0

5.8

6.0

5.8

5.7

5.6

4,297

4,137

3,924

3,824

3,747

3,638

3,551

3.480

7.70

7.12

6.42

5.97

5.57

5.08

4.65

4.27

3,803

3,628

3,396

3,275

3,176

3,040

2,923

2,820

					,	,										
	C	OUTDO	OR LO	<b>)7</b> (15	% Metha	anol)	ELE	CTRIC	AL			INDO	OR LO	OP (Air)		
	ELT (°F)	Evap. Temp.	Flow (gpm)	LLT (°F)	Delta T (°F)	Heat Abs. (Btu/hr)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°F)	Cond. Temp.	Airflow (cfm)	LAT (°F)	Delta T (°F)	Heating (Btu/hr)	СОРн
Ŋ	29	20	3.0	23	5.9	8,397	3.7	104	916		102	400	97	28.8	11,523	3.69
	35	25	3.0	29	6.2	8,862	3.7	104	928		104	400	98	30.1	12,029	3.80
F	41	30	3.0	35	6.5	9,314	3.8	104	938		106	400	99	31.3	12,514	3.91
	47	35	3.0	40	6.9	9,794	3.8	104	939	68	108	400	101	32.5	12,997	4.06
Ĩ	51	40	3.0	44	7.0	10,523	3.9	104	947	00	110	400	102	34.4	13,754	4.26
_	57	45	3.0	49	7.7	11,528	3.9	104	963		112	400	105	37.0	14,815	4.51
	63	50	3.0	55	8.3	12,506	4.0	104	979		114	400	108	39.6	15,847	4.74
	69	55	3.0	60	8.9	13,309	4.1	104	991		116	400	110	41.7	16,689	4.94

#### R/RH-12-HAC-P-1L R410a, 60 Hz, GKS102

																	_	
	C	OUTDO	OR LO	<b>OP</b> (15	% Metha	anol)	ELE	CTRIC	AL			IND	OOR L	.00P (A	ir @ 46	% RH)		
	ELT (°F)	Cond. Temp.	Flow (gpm)	LLT (°F)	Delta T (°F)	Heat Rej. (Btu/hr)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°F)	Evap. Temp.	Airflow (cfm)	LAT (°F)	Delta T (°F)	Latent (Btu/hr)	Sensible (Btu/hr)	Cooling (Btu/hr)	EER
48	51	70	3.0	61	10.4	15,554	2.2	116	498		44	400	57	23.6	4,433	9,421	13,854	27.8
DNIJ	56	75	3.0	66	10.4	15,583	2.4	116	567		44	400	57	23.2	4,367	9,281	13,648	24.1
	61	80	3.0	71	10.4	15,612	2.6	116	630		44	400	58	22.9	4,308	9,154	13,462	21.4
Ō	66	85	3.0	76	10.4	15,530	2.7	116	666	80.6	45	400	58	22.5	4,242	9,014	13,256	19.9
8	72	90	3.0	83	10.8	15,425	2.8	116	694	00.0	45	400	58	22.2	4,178	8,877	13,055	18.8
-	77	95	3.0	88	10.8	15,358	2.9	116	742		45	400	59	21.8	4,104	8,722	12,826	17.3
	82	100	3.0	93	10.7	15,253	3.1	116	787		45	400	59	21.4	4,021	8,546	12,567	16.0
	87	105	3.0	98	10.6	15,164	3.3	116	831		45	400	60	21.0	3,945	8,383	12,328	14.8

М	ETRIC	;																	
i		(	OUTDO	OR LO	<b>OP</b> (15	5% Meth	anol)	ELE	CTRIC	CAL			INDO	OR LO	OP (Air)			1	
		ELT (°C)	Evap. Temp.	Flow (L/s)	LLT (°C)	Delta T (°C)	Heat Abs. (W)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°C)	Cond. Temp.	Airflow (L/s)	LAT (°C)	Delta T (°C)	Heating (W)	СОРн		
	Ð	-1.7 1 7	-6.7	0.19	-4.9	3.3	2,460	3.7 3.7	104	916 928		38.9 40.0	190 190	36.0 36.7	16.0 16.7	3,376	3.69 3.80		
	III	5.0	-1.1	0.19	1.4	3.6	2,729	3.8	104	938		41.1	190	37.4	17.4	3,666	3.91	-	
	HEA	8.3 10.6	1.7 4.4	0.19	4.5 6.7	3.8 3.9	2,870 3,083	3.8 3.9	104 104	939 947	20	42.2 43.3	190 190	38.1 39.1	18.1 19.1	3,808 4,030	4.06 4.26	-	
		13.9	7.2	0.19	9.6	4.3	3,378	3.9	104	963 979		44.4	190	40.6	20.6	4,341	4.51	-	
		20.6	12.8	0.19	15.6	4.9	3,899	4.0	104	991		46.7	190	43.2	23.2	4,890	4.94		
		(	OUTDO	OR LO	<b>OP</b> (15	5% Meth	anol)	ELE	CTRIC	CAL			INC	OOR L	.00P (A	lir @ 46	% RH)		
		ELT (°C)	Cond. Temp.	Flow (L/s)	LLT (°C)	Delta T (°C)	Heat Rej. (W)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°C)	Evap. Temp.	Airflow (L/s)	LAT (°C)	Delta T (°C)	Latent (W)	Sensible (W)	Cooling (W)	
l		10.6	21.1	0.19	16.3	5.8	4,557	2.2	116	498		6.7	190	13.9	13.1	1,299	2,760	4,059	

567

630

666

694

742

787

831

6.8

6.9

7.0

7.1

7.2

7.3

7.4

27

190

190

190

190

190

190

190

12.9

12.7

12.5

12.3

12.1

11.9

11.6

14.1

14.3

14.5

14.7

14.9

15.1

15.4

1,280

1,262

1,243

1,224

1,203

1,178

1,156

2,719

2,682

2,641

2,601

2,555

2,504

2,456

2.4

2.6

2.7

2.8

2.9

3.1

3.3

116

116

116

116

116

116

116

\*\* Fan power at 24.9Pa (0.10inH<sub>2</sub>O) external static.

7.06

6.26

5.83

5.51

5.07

4.68

4.35

3,999

3,944

3,884

3,825

3,758

3,682

3,612

DNIJOOD

23.9

26.7

29.4

32.2

35.0

37.8

40.6

0.19

0.19

0.19

0.19

0.19

0.19

0.19

19.1

21.9

24.6

28.2

31.0

33.7

36.5

5.8

5.8

5.8

6.0

6.0

5.9

5.9

4,566

4,574

4,550

4,519

4,500

4,469

4.443

13.3

16.1

18.9

22.2

25.0

27.8

30.6

		-			,	,										
	U	OUTDO	OR LO	<b>DP</b> (15	% Metha	anol)	ELE	CTRIC	AL			INDO	OR LO	OP (Air)		
	ELT (°F)	Evap. Temp.	Flow (gpm)	LLT (°F)	Delta T (°F)	Heat Abs. (Btu/hr)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°F)	Cond. Temp.	Airflow (cfm)	LAT (°F)	Delta T (°F)	Heating (Btu/hr)	СОРн
40	29	20	4.5	24	4.8	10,359	5.0	135	1,153		102	650	90	22.0	14,294	3.63
<b>N</b>	35	25	4.5	30	5.3	11,354	5.1	135	1,186		104	650	92	23.7	15,403	3.80
F	41	30	4.5	35	5.8	12,408	5.2	135	1,215		106	650	94	25.5	16,554	3.99
	47	35	4.5	41	6.2	13,305	5.4	135	1,255	68	108	650	95	27.1	17,588	4.11
Ï	51	40	4.5	45	6.3	14,233	5.6	135	1,294	00	110	650	97	28.7	18,649	4.22
_	57	45	4.5	50	6.9	15,459	5.7	135	1,316		112	650	99	30.7	19,950	4.44
	63	50	4.5	56	7.5	16,765	5.8	135	1,338		114	650	101	32.8	21,332	4.67
	69	55	4.5	61	8.1	18,158	6.0	135	1,362		116	650	103	35.1	22,805	4.91

#### R/RH-18-HAC-P-1L R410a. 60 Hz. GJS151

																	_	
	C	OUTDO	OR LO	<b>OP</b> (15	% Meth	anol)	ELE	CTRIC	AL			IND	OOR L	.00P (A	ir @ 46	% RH)		
	ELT (°F)	Cond. Temp.	Flow (gpm)	LLT (°F)	Delta T (°F)	Heat Rej. (Btu/hr)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°F)	Evap. Temp.	Airflow (cfm)	LAT (°F)	Delta T (°F)	Latent (Btu/hr)	Sensible (Btu/hr)	Cooling (Btu/hr)	EER
48	51	70	4.5	62	10.7	24,101	4.4	143	884		44	650	59	22.1	6,747	14,337	21,084	23.9
SNI	56	75	4.5	67	10.5	23,538	4.5	143	927		44	650	59	21.3	6,520	13,854	20,374	22.0
	61	80	4.5	71	10.3	23,050	4.6	143	938		44	650	60	20.8	6,352	13,497	19,849	21.2
Ō	66	85	4.5	76	10.0	22,545	4.8	143	974	80.6	45	650	61	20.1	6,151	13,070	19,220	19.7
8	72	90	4.5	82	10.3	22,024	5.0	143	1,022	00.0	45	650	61	19.4	5,932	12,606	18,538	18.1
	77	95	4.5	87	10.2	21,827	5.2	143	1,058		45	650	62	19.1	5,829	12,387	18,217	17.2
	82	100	4.5	92	10.1	21,606	5.5	143	1,102		45	650	62	18.7	5,710	12,134	17,845	16.2
	87	105	4.5	97	10.0	21,363	5.8	143	1,153		45	650	62	18.2	5,577	11,851	17,428	15.1

М	ETRIC	;																	
İ_		(	OUTDO	OR LO	<b>OP</b> (15	% Meth	anol)	ELE	CTRIC	CAL			INDO	OR LO	OP (Air)			]	
		ELT (°C)	Evap. Temp.	Flow (L/s)	LLT (°C)	Delta T (°C)	Heat Abs. (W)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°C)	Cond. Temp.	Airflow (L/s)	LAT (°C)	Delta T (°C)	Heating (W)	СОРн		
i	(h)	-1.7	-6.7	0.28	-4.4	2.7	3,035	5.0	135	1,153		38.9	307	32.2	12.2	4,188	3.63		
i	ž	1.7	-3.9	0.28	-1.3	3.0	3,327	5.1	135	1,186		40.0	307	33.2	13.2	4,513	3.80		
	F	5.0	-1.1	0.28	1.8	3.2	3,636	5.2	135	1,215		41.1	307	34.1	14.1	4,850	3.99		
	HEA	8.3	1.7	0.28	4.9	3.5	3,898	5.4	135	1,255	20	42.2	307	35.0	15.0	5,153	4.11		
		10.6	4.4	0.28	7.0	3.5	4,170	5.6	135	1,294	20	43.3	307	35.9	15.9	5,464	4.22		
i		13.9	7.2	0.28	10.1	3.8	4,529	5.7	135	1,316		44.4	307	37.1	17.1	5,845	4.44		
i		17.2	10.0	0.28	13.1	4.1	4,912	5.8	135	1,338		45.6	307	38.2	18.2	6,250	4.67		
		20.6	12.8	0.28	16.1	4.5	5,320	6.0	135	1,362		46.7	307	39.5	19.5	6,682	4.91		
	j																		
1			JUTDO	OR LO	<b>OP</b> (15	% Meth	anol)	ELE	CTRIC	AL		INDOOR LOOP (Air @ 46% R							
		ELT (°C)	Cond. Temp.	Flow (L/s)	LLT (°C)	Delta T (°C)	Heat Rej. (W)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°C)	Evap. Temp.	Airflow (L/s)	LAT (°C)	Delta T (°C)	Latent (W)	Sensible (W)	Cooling (W)	CO
I.		10.6	21.1	0.28	16.5	6.0	7,062	4.4	143	884		6.7	307	14.7	12.3	1,977	4,201	6,178	6.9
	<b>N</b>	13.3	23.9	0.28	19.1	5.8	6,897	4.5	143	927		6.8	307	15.2	11.8	1,910	4,059	5,970	6.4
I.		16.1	26.7	0.28	21.8	5.7	6,754	4.6	143	938		6.9	307	15.5	11.5	1,861	3,955	5,816	6.2

974

1,022

1,058

1,102

1,153

7.0

7.1

7.2

7.3

7.4

27

307

307

307

307

307

15.8

16.2

16.4

16.6

16.9

11.2

10.8

10.6

10.4

10.1

1,802

1,738

1,708

1,673

1,634

3,829

3,693

3,629

3,555

3,472

5,632

5,431

5,337

5,228

5,106

\*\* Fan power at 24.9Pa (0.10inH<sub>2</sub>O) external static.

0.28

0.28

0.28

0.28

0.28

24.5

27.9

30.7

33.4

36.1

5.6

5.7

5.7

5.6

5.6

6,606

6,453

6,395

6,331

6.259

4.8

5.0

5.2

5.5

5.8

143

143

143

143

143

18.9

22.2

25.0

27.8

30.6

29.4

32.2

35.0

37.8

40.6

1000

6.20

5.78

5.32

5.05

4.74

4.43

	C	DUTDO	OR LO	<b>DP</b> (15	% Meth	anol)	ELE	INDOOR LOOP (Air)								
	ELT (°F)	Evap. Temp.	Flow (gpm)	LLT (°F)	Delta T (°F)	Heat Abs. (Btu/hr)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°F)	Cond. Temp.	Airflow (cfm)	LAT (°F)	Delta T (°F)	Heating (Btu/hr)	СОРн
	25	15	8	22	-3.3	12,900	8.2	185	1,578		101	800	89	20.8	18,000	3.34
ž	30	20	8	26	-3.6	14,100	8.7	185	1,614		103	800	90	22.4	19,350	3.51
F	35	25	8	31	-3.9	15,400	9.2	185	1,651		105	800	92	24.1	20,800	3.69
	40	29	8	36	-4.3	16,750	9.7	185	1,686	68	107	800	94	25.8	22,250	3.87
Ŧ	45	34	8	40	-4.6	18,200	10.1	185	1,723	00	109	800	96	27.6	23,850	4.06
	50	39	8	45	-5.0	19,700	10.4	185	1,759		110	800	98	29.5	25,500	4.25
	55	43	8	50	-5.4	21,300	10.6	185	1,792		112	800	100	31.5	27,200	4.45
	60	48	8	54	-5.9	23,000	10.8	185	1,827		114	800	102	33.6	29,050	4.66

#### R/RH-24-HAC-P-1L R410a, 60 Hz, GJS208

	C	OUTDO	OR LO	<b>OP</b> (15	% Metha	anol)	ELE	CTRIC	AL			IND	OOR L	.00P (A	ir @ 46	% RH)		
	ELT (°F)	Cond. Temp.	Flow (gpm)	LLT (°F)	Delta T (°F)	Heat Rej. (Btu/hr)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°F)	Evap. Temp.	Airflow (cfm)	LAT (°F)	Delta T (°F)	Latent (Btu/hr)	Sensible (Btu/hr)	Cooling (Btu/hr)	EER
48	55	77	8	63	8.1	31,650	7.7	192	1,196		44	800	58	-22.7	7,950	19,650	27,600	23.10
Ň	60	82	8	68	8.0	31,450	8.0	192	1,266		45	800	58	-22.3	7,900	19,300	27,200	21.50
5	65	88	8	73	8.0	31,200	8.6	192	1,334		45	800	59	-21.8	7,850	18,850	26,700	20.00
0	70	93	8	78	7.9	30,800	8.4	192	1,397	906	46	800	59	-21.2	7,750	18,350	26,100	18.70
8	75	98	8	83	7.8	30,400	8.6	192	1,453	00.0	47	800	60	-20.7	7,600	17,900	25,500	17.50
	80	104	8	88	7.6	29,800	8.8	192	1,501		47	800	61	-20.0	7,450	17,300	24,750	16.50
	85	109	8	93	7.5	29,250	8.9	192	1,542		48	800	61	-19.4	7,300	16,750	24,050	15.60
	90	115	8	97	7.3	28,600	9.0	192	1,573		48	800	62	-18.7	7,150	16,150	23,300	14.80

M	EIRIC	;																	
Ì.		(	OUTDO	OR LO	<b>OP</b> (15	5% Meth	anol)	ELE	CTRIC	AL			INDO	OR LO	<b>OP</b> (Air)			1	
		ELT (°C)	Evap. Temp.	Flow (L/s)	LLT (°C)	Delta T (°C)	Heat Abs. (W)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°C)	Cond. Temp.	Airflow (L/s)	LAT (°C)	Delta T (°C)	Heating (W)	COPH	1	
Ì	ø	-3.9	-9.3	0.5	-5.7	-1.8	3,781	8.2	185	1,578		38.4	380	31.6	11.6	5,275	3.34	1	
	ŇL	-1.1 1.7	-6.7 -4.1	0.5 0.5	-3.1	-2.0 -2.2	4,132	8.7 9.2	185 185	1,614 1.651		39.4 40.5	380 380	32.4 33.4	12.4	5,671 6.096	3.51 3.69		
	EAT	4.4	-1.6	0.5	2.0	-2.4	4,909	9.7	185	1,686	20	41.5	380	34.3	14.3	6,521	3.87		
	I	7.2	1.1	0.5	4.6	-2.6 -2.8	5,334 5,774	10.1 10.4	185 185	1,723		42.6	380 380	35.3	15.3	6,990 7 473	4.06		
		12.8	6.2	0.5	9.8	-3.0	6,242	10.6	185	1,792		44.6	380	37.5	17.5	7,972	4.45		
į		15.6	8.8	0.5	12.3	-3.3	6,741	10.8	185	1,827		45.6	380	38.7	18.7	8,514	4.66	J	
		(	OUTDO	OR LO	<b>OP</b> (15	5% Meth	anol)	ELE	CTRIC	AL			IND	OOR L	.00P (A	ir @ 46	% RH)		
		ELT (°C)	Cond. Temp.	Flow (L/s)	LLT (°C)	Delta T (°C)	Heat Rej. (W)	Compressor Current (A)	Fan** (W)	Input Power (W)	EAT (°C)	Evap. Temp.	Airflow (L/s)	LAT (°C)	Delta T (°C)	Latent (W)	Sensible (W)	Cooling (W)	С
	e	12.8	24.8	0.5	17.3	4.5	9,276	7.7	192	1,196		6.8	380	14.4	-12.6	2,330	5,759	8,089	6
	Ň	15.6	27.8	0.5	20.0	4.4	9,217	8.0 8.6	192	1,266		7.1 7.4	380 380	14.6	-12.4	2,315	5,656	7,972	6. 5
	0	21.1	33.8	0.5	25.5	4.4	9,027	8.4	192	1,397	07	7.8	380	15.2	-11.8	2,271	5,378	7,649	5
	8	23.9	36.8	0.5	28.2	4.3	8,909	8.6	192	1,453	21	8.1	380	15.5	-11.5	2,227	5,246	7,473	5
		26.7	39.8	0.5	30.9	4.2	8,734	8.8	192	1,501		8.4	380	15.9	-11.1	2,183	5,070	7,254	4.

\*\* Fan power at 24.9Pa (0.10in $H_2O$ ) external static.

36.3 4.1

8,382

9.0

192

1,573

9.1

380

16.6

32.2 45.9 0.5

6,829

4.34

-10.4 2,095 4,733

## **Electrical Specifications**

TABLE	Elec. Code	Power S	Compressor		Fan	Out- door Circ.	FLA	MCA	Max. Fuse/ Breaker	Min. Wire Size		
		V-ø-Hz	MIN	MAX	RLA	LRA	RLA	Max A	Amps	Amps	Amps	ga
	1	208/ <b>230</b> -1-60	187	253	4.4	20	2.8	1.5	8.9	10.0	15	#14-2
R/RH-09	3	265/277-1-60	226	304	3.4	21	2.6	-	6.2	7.1	15	#14-2
	9	<b>208</b> /230-1-60	187	253	4.4	20	2.8	1.5	8.9	10.0	15	#14-2
	1	208/ <b>230</b> -1-60	187	253	5.5	26	2.8	1.5	10.0	11.4	15	#14-2
R/RH-12	3	265/277-1-60	226	304	4.3	25	2.6	-	7.1	8.2	15	#14-2
	9	<b>208</b> /230-1-60	187	253	5.5	26	2.8	1.5	10.0	11.4	15	#14-2
	1	208/ <b>230</b> -1-60	187	253	7.0	38	2.8	1.5	11.5	13.3	20	#12-2
R/RH-18	3	265/277-1-60	226	304	6.0	28	2.6	-	8.8	10.3	15	#14-2
	9	<b>208</b> /230-1-60	187	253	7.0	38	2.8	1.5	11.5	13.3	20	#12-2
	1	208/ <b>230</b> -1-60	187	253	9.5	43	2.8	1.5	14.0	16.4	20	#12-2
K/KA-24	9	<b>208</b> /230-1-60	187	253	9.5	43	2.8	1.5	14.0	16.4	20	#12-2

TABLE	TABLE 23 - Plenum Heater Electrical Specifications														
Sizo			(230-1-6	0)	(208-1-60)										
(kW)	Actual (kW)	FLA (A)	MCA (A)	Breaker (A)	Wire Size	Actual (kW)	FLA (A)	MCA (A)	Breaker (A)	Wire Size					
5	5	20.8	26.0	30	#10	3.8	18.1	22.6	30	#10					
7	7	29.2	36.5	40	#8	5.3	25.3	31.6	40	#8					
10	10	41.7	52.1	60	#6	7.5	36.1	45.1	50	#6					









## **Dimensions: R-09/12 Left Return**

All dimensions in inches.



### NO BACK CLEARANCE REQUIRED

## **Dimensions: R-09/12 Right Return**

All dimensions in inches.



## **Dimensions: R-18/24 Left Return**

All dimensions in inches.



## **Dimensions: R-18/24 Right Return**

All dimensions in inches.



ISSUE 05: 20-Mar-2024

All dimensions in inches.



**Dimensions: RH-09/12 Left Return** 

### 2 FT

## Dimensions: RH-09/12 Right Return

All dimensions in inches.



All dimensions in inches.

## **Dimensions: RH-18/24 Left Return**



## **Dimensions: RH-18/24 Right Return**

All dimensions in inches.



# LIMITED WARRANTY

MARITIME GEOTHERMAL LTD. warrants that its commercial geothermal heat pumps shall be free from defects in materials and workmanship for a period of ONE (1) YEAR after the date of installation or for a period of ONE (1) YEAR AND SIXTY (60) DAYS after the date of shipment, whichever occurs first. This warranty covers all internal components of the heat pump.

MARITIME GEOTHERMAL LTD. shall, at its option, repair or replace any part covered by this warranty. Defective parts shall be returned to MARITIME GEOTHERMAL LTD., transportation charges prepaid. Replacement or repaired parts and components are warranted only for the remaining portion of the original warranty period.

#### This warranty is subject to the following conditions:

- 1. The geothermal heat pump must be properly installed and maintained in accordance with MARITIME GEOTHERMAL LTD. guidelines.
- 2. The installer must complete the **Startup Record** and return it to MARITIME GEOTHERMAL LTD. within 21 days of unit installation.
- 3. For new construction, it is the responsibility of the building or general contractor to supply temporary heat to the structure prior to occupancy. Geothermal heat pumps are designed to provide heat only to the completely finished and insulated structure. Startup of the unit shall not be scheduled prior to completion of construction and final duct installation for validation of this warranty.
- 4. It is the customer's responsibility to supply the proper quantity and quality of water or properly sized ground loop with adequate freeze protection.

If a geothermal heat pump manufactured by MARITIME GEOTHERMAL LTD. fails to conform to this warranty, MARITIME GEOTHERMAL LTD.'s sole and exclusive liability shall be, at its option, to repair or replace any part or component which is returned by the customer during the applicable warranty period set forth above, provided that (1) MARITIME GEOTHERMAL LTD. is promptly notified in writing upon discovery by the customer that such part or component fails to conform to this warranty; (2) the customer returns such part or component to MARITIME GEOTHERMAL LTD., transportation charges prepaid, within (30) thirty days of failure, and (3) MARITIME GEOTHERMAL LTD.'s examination of such component discloses to its satisfaction that such part or component fails to conform to this warranty and the alleged defects were not caused by accident, misuse, neglect, alteration, improper installation, repair or improper testing. MARITIME GEOTHERMAL LTD. will not be responsible for any consequential damages or labour costs incurred. In additional, MARITIME GEOTHERMAL LTD, will not be responsible for the cost of replacement parts purchased from a third party.